

WTI Part No. 14439
Rev. A

SRM
Secure Rack Modems

User's Guide



Power & Console Solutions | wti.com



Warnings and Cautions: Installation Instructions



Secure Racking

If Secure Racked units are installed in a closed or multi-unit rack assembly, they may require further evaluation by Certification Agencies. The following items must be considered.

1. The ambient within the rack may be greater than room ambient. Installation should be such that the amount of air flow required for safe operation is not compromised. The maximum temperature for the equipment in this environment is 60°C. Consideration should be given to the maximum rated ambient.
2. Installation should be such that a hazardous stability condition is not achieved due to uneven loading.

Input Supply

1. Check nameplate ratings to assure there is no overloading of supply circuits that could have an effect on overcurrent protection and supply wiring.
2. When installing -48 VDC rated equipment, it must be installed only per the following conditions:
 - A. Connect the equipment to a 48 VDC supply source that is electrically isolated from the alternating current source. The 48 VDC source is to be connected to a 48 VDC SELV source.
 - B. Input wiring to terminal block must be routed and secured in such a manner that it is protected from damage and stress. Do not route wiring past sharp edges or moving parts.
 - C. A readily accessible disconnect device, with a 3 mm minimum contact gap, shall be incorporated in the fixed wiring.

Grounding

Reliable earthing of this equipment must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than direct connections to the branch circuit.

No Serviceable Parts Inside; Authorized Service Personnel Only

Do not attempt to repair or service this device yourself. Internal components must be serviced by authorized personnel only.

- **Shock Hazard - Do Not Enter**
- **Lithium Battery**
CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with same or equivalent type recommended by the manufacturer.
Discard used batteries according to the manufacturer's instructions.

Disconnect Power

If any of the following events are noted, immediately disconnect the unit from the outlet and contact qualified service personnel:

1. If the power cord becomes frayed or damaged.
2. If liquid has been spilled into the device or if the device has been exposed to rain or water.

Disconnect Power Before Servicing

Before attempting to service or remove this unit, please make certain to disconnect the power supply cable from the power source.

Modem Cables

CAUTION: To reduce the risk of fire, use only No. 26 AWG or larger (e.g., 24 AWG) UL Listed or CSA Certified Telecommunication Line Cord.

Agency Approvals

FCC Part 15 Regulation

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

WARNING: *Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment*

EMC, Safety, and R&TTE Directive Compliance

The CE mark is affixed to this product to confirm compliance with the following European Community Directives:

- **Council Directive 2004/108/EC of 15 December 2004 on the approximation of the laws of Member States relating to electromagnetic compatibility;**
and
- **Council Directive 2006/95/EC of 12 December 2006 on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits;**
and
- **Council Directive 1999/5/EC of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.**

Industry Canada - EMI Information

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

This product meets the applicable Industry Canada technical specifications

The Ringer Equivalence Number is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

Table of Contents

1. Introduction	1-1
2. Unit Description	2-1
2.1. Front Panel	2-1
2.2. Back Panel	2-2
2.3. Front Panel Button Functions	2-3
3. Getting Started	3-1
3.1. Apply Power to the SRM	3-1
3.2. Connect Your PC to the SRM	3-1
3.3. Communicating with the SRM	3-2
3.4. Basic Modem Commands	3-4
3.5. The WMU Enterprise Management Solution	3-5
4. Hardware Installation	4-1
4.1. Connecting the Power Supply Cables	4-1
4.1.1. Connect the SRM to Your Power Supply	4-1
4.1.2. Installing the Power Supply Cable Keeper	4-1
4.1.3. DC Powered Units	4-1
4.2. Cable Connection	4-2
4.2.1. Connecting the Network Cable	4-2
4.2.2. The Modem Port	4-2
4.2.3. The SetUp Ports	4-2
4.2.4. The Phone Line Port	4-2
5. Basic Operation	5-1
5.1. Communicating with the SRM Unit via Network or Setup Port	5-1
5.1.1. The Text Interface	5-1
5.1.2. The Web Browser Interface	5-3
5.1.3. Access via Mobile Device	5-4
5.2. Configuring the SRM for Common Applications	5-5
5.2.1. Dial-Up Access to a Device Connected to the SRM Modem Port	5-5
5.2.1.1. Alternate Configuration for Dial-Up Access to Connected Device	5-5
5.2.2. Network Accessible Shared Modem	5-6
5.2.2.1. Alternate Configuration for Network Accessible Modem Application	5-6
5.2.3. Dial-Up Access to Outbound SSH/Telnet	5-7
5.3. Dialing Commands	5-7
5.4. Manual Operation	5-7
5.5. Logging Out of Command Mode	5-7
6. Configuration Options	6-1
6.1. Configuration Menus	6-1
6.2. Defining System Parameters	6-2
6.2.1. The Real Time Clock and Calendar	6-5
6.2.2. The Serial Port Invalid Access Lockout Feature	6-7
6.2.3. Log Configuration	6-10
6.2.3.1. The Audit Log and Alarm Log Configuration Options	6-10
6.2.3.2. The Temperature Log	6-10
6.2.3.3. Reading, Downloading and Erasing Logs	6-11
6.2.4. Callback Security	6-12
6.2.5. Scripting Options	6-13
6.3. User Accounts	6-15
6.3.1. Command Access Levels	6-15
6.3.2. Granting Serial Port Access	6-16

6. Configuration Options (continued)	
6.4. Managing User Accounts	6-17
6.4.1. Viewing User Accounts	6-17
6.4.2. Adding User Accounts	6-17
6.4.3. Modifying User Accounts	6-19
6.4.4. Deleting User Accounts	6-19
6.5. Modem and Serial Port Configuration	6-20
6.5.1. Modem Modes	6-20
6.5.2. The Serial Port Configuration Menus	6-20
6.5.2.1. Serial SetUp Port Parameters	6-21
6.5.2.2. Serial Modem Port Parameters	6-21
6.5.2.3. Internal Modem Parameters	6-22
6.6. Network Configuration	6-26
6.6.1. Network Port Parameters	6-27
6.6.2. Network Parameters	6-29
6.6.3. IP Security	6-34
6.6.3.1. Adding IP Addresses to the Allow and Deny Lists	6-35
6.6.3.2. Linux Operators and Wild Cards	6-36
6.6.3.3. IP Security Examples	6-36
6.6.4. Static Route	6-37
6.6.5. Domain Name Server	6-37
6.6.6. SNMP Access Parameters	6-38
6.6.7. SNMP Trap Parameters	6-40
6.6.8. LDAP Parameters	6-41
6.6.8.1. Adding LDAP Groups	6-43
6.6.8.2. Viewing LDAP Groups	6-44
6.6.8.3. Modifying LDAP Groups	6-44
6.6.8.4. Deleting LDAP Groups	6-44
6.6.9. TACACS Parameters	6-45
6.6.10. RADIUS Parameters	6-47
6.6.10.1. Dictionary Support for RADIUS	6-49
6.6.11. Email Messaging Parameters	6-50
6.7. Save User Selected Parameters	6-51
6.7.1. Restore Configuration	6-51
7. Alarm Configuration	7-1
7.1. The Over Temperature Alarms	7-2
7.2. The Ping-No-Answer Alarm	7-4
7.2.1. Ping-No-Answer Notification	7-4
7.2.1.1. Defining Ping No Answer IP Addresses	7-4
7.2.1.2. Configuring the Ping No Answer Alarm	7-6
7.3. The Serial Port Invalid Access Lockout Alarm	7-8
7.4. The Power Cycle Alarm	7-10
7.5. The No Dialtone Alarm	7-11
8. The Status Screens	8-1
8.1. Product Status	8-1
8.2. The Network Status Screen	8-1
8.3. The Port Status Screen	8-2
8.4. The Port Diagnostics Screen	8-2
8.5. The Alarm Status Screen	8-2
8.6. The Port Parameters Screens	8-3
8.7. The Event Logs	8-4
8.7.1. The Audit Log	8-4
8.7.2. The Alarm Log	8-4
8.7.3. The Temperature Log	8-4

9. Telnet & SSH Functions	9-1
9.1. Network Port Numbers	9-1
9.2. SSH Encryption	9-1
9.3. Creating an Outbound Telnet Connection	9-2
9.4. Creating an Outbound SSH Connection	9-3
10. Syslog Messages	10-1
10.1. Configuration	10-1
11. Operation via SNMP	11-1
11.1. SRM SNMP Agent	11-1
11.2. SNMPv3 Authentication and Encryption	11-1
11.3. Configuration via SNMP	11-2
11.3.1. Viewing Users	11-3
11.3.2. Adding Users	11-3
11.3.3. Modifying Users	11-3
11.3.4. Deleting Users	11-3
11.4. Configuring Serial Ports	11-3
11.5. Viewing Unit Status via SNMP	11-4
11.5.1. System Status - Ethernet Port Mac Addresses	11-4
11.5.2. Unit Temperature Status	11-4
11.5.3. Alarm Status	11-4
11.6. Sending Traps via SNMP	11-5
12. Setting Up SSL Encryption	12-1
12.1. Creating a Self Signed Certificate	12-2
12.2. Creating a Signed Certificate	12-3
12.3. Downloading the Server Private Key	12-4
12.4. TLS Mode	12-5
13. Saving and Restoring Configuration Parameters	13-1
13.1. Sending Parameters to a File	13-1
13.1.1. Downloading & Saving Parameters via Text Interface	13-1
13.1.2. Downloading & Saving Parameters via Web Browser Interface	13-2
13.2. Restoring Downloaded Parameters	13-2
13.3. Restoring Recently Saved Parameters	13-3
14. Upgrading SRM Firmware	14-1
14.1. WMU Enterprise Management Software (Recommended)	14-1
14.2. The Upgrade Firmware Function (Alternate Method)	14-1
15. Command Reference Guide	15-1
15.1. Command Conventions	15-1
15.2. Command Summary	15-2
15.3. Command Set	15-3
15.3.1. Display Commands	15-3
15.3.2. Control Commands	15-6
15.3.3. Configuration Commands	15-9
Appendices:	
A. Specifications	Apx-1
B. Interface Descriptions	Apx-2
C. Customer Service	Apx-4

List of Figures

2.1.	Front Panel	2-1
2.2.	Back Panel.	2-2
4.1.	Terminal Block Assembly (DC Units Only)	4-1
12.1.	Web Access Parameters (Text Interface Only).	12-1
B.1.	RJ45 SetUp Port (DTE)	Apx-2
B.2.	DB25 Modem Port (DCE)	Apx-2
B.3.	RJ45 Modem Port (DCE).	Apx-2
B.4.	RJ11 Phone Line Port	Apx-3

1. Introduction

The SRM Secure Rack Modem is designed for applications that require secure, dial-up access to remote, rack mounted network elements. In addition to password security and a multi-level user directory, the SRM also supports SSHv2 encryption, IP address filtering and HTTPS/SSL Secure web, plus popular authentication protocols such as LDAP, Kerberos, TACACS+ and RADIUS.

In order to simplify the process of configuring and managing modem functions, administrators can access the SRM via Ethernet Port, RJ45 Serial port or USB Mini Port. A convenient logging function tracks user activity, alarms, rack temperatures and other factors to provide administrators with an audit trail of events and environmental conditions.

Security and Co-Location Features:

Secure Shell (SSHv2) encryption and address-specific IP security masks help to prevent unauthorized access to command and configuration functions.

The SRM provides four different levels of security for user accounts: Administrator, SuperUser, User and ViewOnly. The Administrator level provides complete access to all serial port and switched plug functions, status displays and configuration menus. The SuperUser level allows control of serial ports and plugs, but does not allow access to configuration functions. The User level allows access to only a select group of Administrator-defined serial ports and plugs. The ViewOnly level allows you to check unit status, but does not allow control of serial ports or switched outlets or access to configuration menus.

WTI Management Utility

SRM units include the WTI Enterprise Management Utility (WMU,) which allows you to manage multiple WTI units via a single menu. For more information on the Enterprise Management Utility, please refer to the WMU User's Guide, which can be downloaded from the WTI web site at: <http://www.wti.com/t-product-manuals.aspx>.

Typographic Conventions

<code>^</code> (e.g. <code>^x</code>)	Indicates a control character. For example, the text " <code>^x</code> " (Control X) indicates the [Ctrl] key and the [X] key must be pressed simultaneously.
COURIER FONT	Indicates characters typed on the keyboard. For example, <code>/RB</code> or <code>/ON 2</code> .
[Bold Font]	Text set in bold face and enclosed in square brackets, indicates a specific key. For example, [Enter] or [Esc] .
<code>< ></code>	Indicates required keyboard entries: For Example: <code>/P <n></code> .
<code>[]</code>	Indicates optional keyboard entries. For Example: <code>/P [n]</code> .

2. Unit Description

2.1. Front Panel




Figure 2.1: Front Panel

As shown in Figure 2.1, the SRM front panel includes the following components:

- ① **RESET:** Can be used to restart the SRM operating system as described in Section 2.3.
- ② **DEFAULT:** Can be used to initialize the SRM to default parameters as described in Section 2.3.
- ③ **ON:** Lights when AC Power is applied.
- ④ **RDY:** (Ready) Flashes when the unit is ready to receive commands.
- ⑤ **Modem Status Indicators:** Four LEDs which function as follows:
 - **DCD:** (Data Carrier Detect) Lights when the DCD signal is present.
 - **RXD:** (Recieve Data) Lights when the RXD signal is present.
 - **DTR:** (Data Terminal Ready) Lights when the DTR signal is present.
 - **TXD:** (Transmit Data) Lights when the TXD signal is present.
- ⑥ **Set Up Port Activity LED:** Lights when the SetUp Port (Console Port) is active.
- ⑦ **Modem Port Activity LED:** Lights when the Modem Port is active.
- ⑧ **Dialtone:** Lights when a dialtone is detected.




Figure 2.2: Back Panel

2.2. Back Panel

As shown in Figure 2.2, the SRM Back Panel includes the following components:

- ① **Power Inlet:** An IEC-320-C14 inlet, for connection to your 100 to 240 VAC power supply.

Note: 48 VDC powered models include a terminal block assembly (see Figure 4.1) in place of the power inlet. For more information, please refer to Section 4.1.3.
- ② **Switched Contact:** A dry contact that can be connected to an external alarm unit. When an external alarm unit is connected to the Switched Contact, the alarm unit will be activated when the No Dialtone Alarm is triggered. For more information on the No Dialtone Alarm, please refer to Section 7.5. The switched contact includes three pins: A Normally Closed (NC) pin, a Common (COM) pin and a Normally Open (NO) pin. The switched contact is rated for 2 Amps maximum.
- ③ **SetUp Ports:** A USB Mini Port and an RJ45 Serial Port that can be used to connect a local device to the SRM unit as described in Section 4.2. For a description of the Setup Port interface, please refer to Appendix B.
- ④ **Modem Ports:** An RJ45 RS232 serial port (DCE configuration) and a DB25 serial port that can be used for connection to a PC or tablet.
- ⑤ **Network Port:** An RJ45 Ethernet port for connection to your 10/100Base-T, TCP/IP network. Note that the SRM features a default, IPv4 format IP address (192.168.168.168). This allows you to connect to the unit without first assigning an IP address. Note that the Network Port also includes two, small LED indicators for Link and Data Activity. For more information on Network Port configuration, please refer to Section 6.6.
- ⑥ **Phone Line Port:** The phone line port is used for connection to your external phone line.

2.3. Front Panel Button Functions

The front panel buttons can be used to perform several functions described below:

Notes:

- *Front Panel button functions can also be disabled via the System Parameters menu, as described in Section 6.2.*
- *When the SRM is reset to factory defaults, all user-defined configuration parameters will be cleared and the default “super” user account will also be restored.*
- *During the reboot procedure, all port activity LEDs will flash once.*

1. Reboot Operating System - Keep User-Defined Parameters:

- a) Press and hold the CLEAR (or RESET) button for five seconds, and then release.
- b) The SRM operating system will reboot; all user-defined parameters will be retained.

2. Reboot Operating System - Reset All Parameters to Factory Defaults:

- a) Simultaneously press both the SET (or DEFAULT) button and the CLEAR (or RESET) button, hold them for five seconds, and then release.
- b) The SRM operating system will reboot; all user-defined parameters will be reset to factory default settings.

Note: *The RDY Indicator will continue to blink for about 45 seconds while parameters are being erased and keys are rebuilt. The RDY Indicator will then stop blinking during the reboot.*

3. Getting Started

This section describes a simplified installation procedure for the SRM hardware, which will allow you to communicate with the unit in order to demonstrate basic features and check for proper operation. Note that this Quick Start procedure does not provide a detailed description of unit configuration, or discuss advanced operating features in detail. For more information, please refer to the remainder of this User's Guide.

3.1. Apply Power to the SRM

Refer to the safety precautions listed at the beginning of this User's Guide, and then connect the unit to an appropriate power source. Connect the power supply cable to the unit's power inlet, snap the Cable Keeper into place, and then connect the cable to an appropriate power supply. Please refer to the power rating label on the unit concerning power requirements and maximum load.

When power is applied to the SRM, the ON LED on the instrument front panel should light, and the RDY LED should begin to flash within 90 seconds. This indicates that the unit is ready to receive commands.

3.2. Connect Your PC to the SRM

The SRM can either be controlled via local PC Serial Port, USB Mini Port, modem, or TCP/IP network. In order to connect ports or select parameters, commands are issued to the SRM via either the Network Port, Modem or Setup Port. Note that it is not necessary to connect to both the Network and Setup Ports.

- **Network Port:** Connect your network interface to the SRM's Network port.
- **SetUp Port:** Connect your PC COM Port to either the RJ45 Serial SetUp Port or USB Mini Port.
 - ▶ **RJ45 SetUp Port:** When connecting to the RJ45 SetUp Port, use the supplied DX9F-DTE-RJ adapter and RJ45 Ethernet cable to connect your PC COM port to the SRM's SetUp Port (Serial Port 1.) For a description of the RJ45 SetUp Port, please refer to Figure B.1.
 - ▶ **USB Mini SetUp Port:** When connecting to the USB Mini Port, use a standard USB Mini Port cable.
- **Modem Port:** The Modem Port includes both a DB25 Connector and an RJ45 connector. Note that both ports cannot be used at the same time. In the default state the Modem is connected to the Modem Port.
 - ▶ **DB25 Modem Port:** When connecting a PC or other device to the DB25 Modem Port use a standard Modem Cable. For pinout, see Figure B.2.
 - ▶ **RJ45 Modem Port:** When connecting a PC or other device to the RJ45 connector, use a standard Ethernet patch cable. For pinout, see Figure B.3.
- **Phone Line:** Connect your phone line to the SRM's RJ11 Phone Line Port. For a description of the RJ11 Phone Line Port pinout, please refer to Figure B.4.

3.3. Communicating with the SRM

The SRM command mode can be used to configure the unit's internal modem, selected communication parameters, define user accounts and to perform other unit management related functions. When properly installed and configured, the SRM will allow command mode access via Telnet, Web Browser, SSH client, modem, or local PC. However, in order to ensure security, both Telnet and Web Browser access are disabled in the default state. To enable Telnet and/or Web Browser access, please refer to Section 6.6.2.

Notes:

- *Default SRM serial port parameters are set as follows: 9600 bps, RTS/CTS Handshaking, 8 Data Bits, One Stop Bit, No Parity. Although these parameters can be easily redefined, for this Quick Start procedure, it is recommended to configure your communications program to accept the default parameters.*
 - *The SRM features a default IP Address (192.168.168.168) and a default Subnet Mask (255.255.255.0.) This allows network access to command mode, providing that you are contacting the SRM from a node on the same subnet. When attempting to access the SRM from a node that is not on the same subnet, please refer to Section 6.6 for further configuration instructions.*
 - *When connecting only a single network cable to a SRM unit that includes two Ethernet ports, make certain to connect to Port ETH0 (the upper Ethernet Port.)*
1. **Access Command Mode:** The SRM includes two separate user interfaces; the Text Interface and the Web Browser Interface. The Text Interface is available via Local PC, SSH Client, or Telnet and can be used to both configure the SRM and create connections between ports. The Web Browser interface is only available via TCP/IP network, and can be used to configure the unit, but cannot create connections between ports.
 - a) **Via SetUp Port:** Start your communications program, then select the appropriate COM port and press [Enter]. Note that when viewed by a PC running Windows XP or later, the Serial COM Port menu will list the USB Mini Port as, "USB to Serial."
 - b) **Via SSH Client:** Start your SSH client, enter the default IP address (192.168.168.168) for the SRM and invoke the connect command.
 - c) **Via Web Browser:** Make certain that Web Browser access is enabled as described in Section 6.6.2. Start your JavaScript enabled Web Browser, enter the default IPv4 format SRM IP address (192.168.168.168) in the Web Browser address bar, and then press [Enter].
 - d) **Via Telnet:** Make certain that Telnet access is enabled as described in Section 6.6.2. Start your Telnet client, and enter the SRM's default IPv4 format IP address (192.168.168.168).

2. **Username / Password Prompt:** A message will be displayed, which prompts you to enter your username (Login) and password.. The default username is "**super**" (all lower case, no quotes), and the default password is also "**super**". If a valid username and password are entered, the SRM will display either the Main Menu (Web Browser Interface) or the Port Status Screen (SSH, Telnet, or Modem.)

Notes:

- *The default Username is "super".*
 - *The default Password is "super"*
 - *If a Login Banner has been defined as described in Section 6.2, then a banner page will appear before the command interface is displayed. The Login Banner can be used to display legal warnings or other information.*
3. **Review Help Menu:** If you are communicating with the SRM via the text interface (SSH, Telnet or Modem), type `/h` and press **[Enter]** to display the Help Menu, which lists all available SRM commands. Note that the Help Menu is not available via the Web Browser Interface.

3.4. Basic Modem Commands

This section describes basic Modem AT commands that can be used to demonstrate basic modem capabilities. For a complete list of available modem commands, please refer to the AT Command Reference Guide, which can be found in WTI's online User's Guide Archive at: <http://www.wti.com/t-product-manuals.aspx>

- AT** Attention command. Must be included as a prefix for all commands unless otherwise noted.
- +++** Switches Modem from data mode to command mode. This command is not preceded by the AT command. The +++ command can be used in conjunction with the Hn command to disconnect a session. To disconnect, enter the +++ command followed by a one second delay, type **ATH** and then press **[Enter]**
(e.g., +++ **ATH** **[Enter]**)
- A** Tells the modem to attempt to answer an incoming call. (e.g., **ATA**)
- Dn** Causes the modem to dial the number *n*. Offers the following command options: **T** (Tone Dialing,) **P** (Pulse dialing,) **-** (Pause 2 seconds,) **@** (Wait for 5 seconds of silence,) **L** (Call last number dialed.) (e.g., **ATD 5551212**)
- En** Toggles command echo On/Off. Allows commands to either be displayed or hidden (0 = Off, 1 = On.) (e.g., **ATE1**)
- Hn** When data mode is active, this command instructs modem to hang up or pick up (0 = hang up, 1 = pick up.) (e.g., **ATH1**)
- Qn** Displays/hides result codes. (0 = Display result codes, 1 = Hide Result codes.) (e.g., **ATQ1**)
- S0=n** Number of rings to answer. (e.g., **ATS0=1** will cause the modem to answer on the first ring.)
- Z** Soft Reset. Restores basic defaults. (e.g., **ATZ**)
- &Fn** Resets modem to factory settings. (0 = Fetch default configuration, 1 = Recall factory default configuration, 2 = Recall Sierra factory default for auto.) (e.g., **AT&F1**)

3.5. The WMU Enterprise Management Solution

The WMU Enterprise Management Solution provides a centralized interface that can be used to configure, manage and control multiple WTI out-of-band management devices spread throughout a large corporate network infrastructure. When installed at your network operation center or support facility, the WMU eliminates the need to individually access WTI units in order to perform firmware updates, edit user accounts and perform other management and control functions.

The WMU software and user's guide can be downloaded at:

<ftp://wtiftp.wti.com/pub/TechSupport/WMU/WtiManagementUtilityInstall.exe>

This completes the Quick Start procedure for the SRM. Prior to placing the unit into operation, it is recommended to refer to the remainder of this user's guide for important information regarding advanced configuration capabilities and more detailed operation instructions. If you have further questions regarding the SRM unit, please contact WTI Customer Support as described in Appendix C.

4. Hardware Installation

4.1. Connecting the Power Supply Cables

4.1.1. Connect the SRM to Your Power Supply

Refer to the cautions listed below and at the beginning of this User's Guide, and then connect the SRM unit to an appropriate power supply.



CAUTIONS:



- *Before attempting to install this unit, please review the warnings and cautions listed at the front of the user's guide.*
- *This device should only be operated with the type of power source indicated on the instrument nameplate. If you are not sure of the type of power service available, please contact your local power company.*
- *Reliable earthing (grounding) of this unit must be maintained. Particular attention should be given to supply connections when connecting to power strips, rather than directly to the branch circuit.*

4.1.2. Installing the Power Supply Cable Keeper

The SRM includes a cable keeper, which is designed to prevent the AC power supply cable from being accidentally disconnected from the unit.

When attaching power supply cable(s) to the unit, first swing the cable keeper out of the way, then plug the power cable securely into the power input. When the cable is in place, snap the cable keeper over the plug to secure the cable to the unit.

4.1.3. DC Powered Units

When connecting a DC Powered SRM unit to your DC Power source, note that the DC terminal block is designed for connection to two separate power sources. First remove the protective cover from the terminal block, attach the wires from the -48 VDC power sources to the screw terminals, connect the ground line to the labeled ground screw, tighten the screw terminals, making certain that the wires are securely fastened, and then replace the protective cover.




Figure 4.1: Terminal Block Assembly (DC Units Only)

4.2. Cable Connection

4.2.1. Connecting the Network Cable

The Network Port is an RJ45 Ethernet jack, for connection to a TCP/IP network. Connect your 100Base-T cable to the Network Port. Note that the SRM includes a default IPv4 protocol IP address (192.168.168.168) and a default IPv4 protocol subnet mask (255.255.255.0.) When installing the SRM in a working network environment, it is recommended to define network parameters as described in Section 6.6.

4.2.2. The Modem Port

The Modem Port includes both a DB25 Connector and an RJ45 connector. Note that both ports cannot be used at the same time. In the default state the internal Modem is connected to the Modem Port. For a description of the Modem Port pinout, please refer to Appendix B.

- **DB25 Modem Port:** When connecting a PC or other device to the DB25 Modem Port use a standard Modem Cable. For pinout, see Figure B.2.
- **RJ45 Modem Port:** When connecting a PC or other device to the RJ45 connector, use a standard Ethernet patch cable. For pinout, see Figure B.3.

4.2.3. The SetUp Ports

In order to select configuration parameters and review unit status, commands are issued to the SRM via either the Network Port or Setup Port. Note that it is not necessary to connect to both the Network and Setup Ports. Connect your PC COM Port to either the RJ45 format Serial SetUp Port or USB Mini format SetUp Port. For a description of the RJ45 SetUp Port pinout, please refer to Appendix B.

- **RJ45 SetUp Port:** When connecting to the RJ45 SetUp Port, use the supplied DX9F-DTE-RJ adapter and RJ45 Ethernet cable to connect your PC COM port to the SRM's SetUp Port (Serial Port 1.)
- **USB Mini SetUp Port:** When connecting to the USB Mini Port, use a standard USB Mini Port cable.

4.2.4. The Phone Line Port

Connect your RJ11 phone line to the RJ11 Phone line connector. For information on Modem configuration, please refer to Section 6.5.2.3. For a description of the Phone Line Port pinout, please refer to Appendix B.

This completes the SRM installation instructions. Please proceed to the next Section for instructions regarding basic unit configuration.

5. Basic Operation

5.1. Communicating with the SRM Unit via Network or Setup Port

In order to configure the SRM, you must connect to the unit via Network or Setup Port, and access command mode. Note that, the SRM offers two separate configuration interfaces; the Web Browser Interface and the Text Interface. The Web Browser interface is only available via network, and the Text Interface is available via network (SSH or Telnet) or local PC.

Notes:

- *In order to access the SRM command mode via modem, you must first disable the Password Bypass and Modem Passthrough parameters as described in Section 6.5.2.3.*
- *If the Password Bypass and Modem Passthrough parameters are disabled, refer to Section 5.2.1.1 for instructions regarding dial-up access to a device attached to the SRM's Serial Modem Port.*

5.1.1. The Text Interface

The Text Interface (also known as the "Command Line Interface" or "CLI") consists of a series of simple ASCII text menus, which allow you to set options and define parameters by entering the number for the desired option using your keyboard, and then typing in the value for that option.

For security purposes, the Web Browser Interface and Telnet accessibility are both disabled in the default state, therefore in order to access command mode functions via Telnet or Web Browser, you will need to use the Text Interface to contact the unit via Local PC or SSH connection when setting up the unit for the first time. After accessing command mode using the Text Interface, you can then enable Web Access and Telnet Access as described in Section 6.6.2, in order to allow future communication with the unit via Web Browser or Telnet. You will not be able to contact the unit via Web Browser or Telnet until you have enabled those options.

Once Telnet Access is enabled, you will then be able to use the Text Interface to communicate with the SRM via local PC, Telnet or SSH connection.

In order to use the Text Interface, your installation must include:

- **Access via Network:** The SRM must be connected to your TCP/IP Network, and your PC must include a communications program (such as HyperTerminal, TeraTerm, Putty or a similar terminal emulation program.)
- **Access via Local PC:** Your PC must be connected to one of the SRM's two available SetUp Ports, the SetUp Port must be configured for Any-to-Any Mode (default,) and your PC must include a communications program (such as HyperTerminal, TeraTerm, Putty or a similar terminal emulation program.)

To access command mode via the Text Interface, proceed as follows:

Note: *When communicating with the unit for the first time, you will not be able to contact the unit via Telnet until you have accessed command mode, via the SRM's SetUp port, and used the Network Parameters Menu to enable Telnet as described in Section 6.6.2.*

1. Contact the SRM Unit:
 - a) **Via Local PC:** Start your communications program and press **[Enter]**. Wait for the connect message, then proceed to Step 2. Note that when viewed by a PC running Windows XP or later, the Serial COM Port menu will list the USB Mini Port as, "USB to Serial."
 - b) **Via Network:** The SRM includes a default IPv4 format IP address (192.168.168.168) and a default IPv4 format subnet mask (255.255.255.0.) This allows you to contact the unit from any network node on the same subnet, without first assigning an IP Address to the unit. For more information, please refer to Section 6.6.
 - i. **Via SSH Client:** Start your SSH client, and enter the SRM's IP Address. Invoke the connect command, wait for the connect message, then proceed to Step 2.
 - ii. **Via Telnet:** Start your Telnet Client, and then Telnet to the SRM's IP Address. Wait for the connect message, then proceed to Step 2.
 - c) **Via Modem:** Use your communications program to dial the number for the phone line that you have connected to the SRM's Modem Port. When a dial-up connection is established,
2. **Login / Password Prompt:** A message will be displayed, which prompts you to enter a username (login name) and password. The default username is "**super**" (all lower case, no quotes), and the default password is also "**super**".

Note: *If a Login Banner has been defined as described in Section 6.2, then a banner page will appear before the command prompt is displayed. The Login Banner can be used to display legal warnings or other information.*

5.1.2. The Web Browser Interface

The Web Browser Interface consists of a series of web forms, which can be used to select configuration parameters by selecting buttons and/or entering text into designated fields.

Note: *In order to use the Web Browser Interface, Web Access must first be enabled via the Text Interface Network Parameters Menu (IN), the SRM must be connected to a TCP/IP network, and your PC must be equipped with a JavaScript enabled web browser.*

1. Start your JavaScript enabled Web Browser, key the SRM's default IPv4 format IP address (192.168.168.168) into the web browser's address bar, and press **[Enter]**.
2. **Username / Password Prompt:** A message box will prompt you to enter your username and password. The default username is "**super**" (all lower case, no quotes), and the default password is also "**super**".

Note: *If a Login Banner has been defined as described in Section 6.2, then a banner page will appear before the command prompt is displayed. The Login Banner can be used to display legal warnings or other information.*

5.1.3. Access via Mobile Device

In addition to the Web Browser Interface and Text Interface, the SRM command mode can also be accessed by mobile devices. Note however, that due to nature of most mobile devices, only a limited selection of SRM operating and status display functions are available to users who communicate with the unit via mobile device.

When the SRM is operated via a Mobile device, only the following functions are available:

- Product Status Screen (Unit Info) (Section 8.1)
- Port Status Screen (Section 8.3)

Note: *Mobile device users are not allowed to change or review SRM configuration parameters.*

For more information on these functions, please refer to the appropriate section listed next to each function in the list above.

To configure the SRM for access via mobile device, first consult your IT department for appropriate settings. Access the SRM command mode via the Text Interface or Web Browser interface as described in this section, then configure the SRM's Network Port accordingly, as described in Section 6.6.

In most cases, this configuration will be adequate to allow communication with most mobile devices. Note however, that if you wish to use a BlackBerry® to contact the SRM, you must first make certain to configure the BlackBerry to support HTML tables, as described below:

1. Power on the BlackBerry, and then click on the BlackBerry Internet Browser Icon.
2. Press the Menu button, and then choose "Options."
3. From the Options menu, choose "Browser Configuration," then verify to make certain that "Support HTML Tables" is checked (enabled.)
4. Press the Menu button, and select "Save Options."

When you have finished communicating with the SRM via mobile device, it is important to always close the session using the mobile device's menu functions, rather than by simply closing the browser window, in order to ensure that the SRM has completely exited from command mode, and is not waiting for the inactivity timeout period to elapse. For example, to close a session on a BlackBerry, press the Menu button and then choose "Close."

5.2. Configuring the SRM for Common Applications

Depending on the configuration parameters selected, the SRM can be used for the following types of applications:

- Dial-Up Access to a Device Connected to the Modem Port
- Network Accessible Shared Modem
- Dial-Up Access to Outbound SSH/Telnet

The sections that follow describe both the configuration requirements and procedure used for employing the SRM in each of these three applications.

Note: For further instructions regarding configuring SRM Modem parameters, please refer to Section 6.5.2.3.

5.2.1. Dial-Up Access to a Device Connected to the SRM Modem Port

The most common application for the SRM is to provide remote, dial-up access to a managed device connected to the SRM's Modem Port. In the event of a network outage, dial-up access provides support personnel with an out-of-band avenue for communication that can be used to access command functions on the managed device in order to restore network communication. In the default state, SRM Modem parameters are set to allow dial-up communication to a device connected to the Modem port.

If you have previously altered the configuration of the SRM, then parameters for the SRM's internal modem should be set as follows in order to allow dial-up access to a device connected to the SRM Modem Port:

Note: For further instructions regarding configuring SRM Modem parameters, please refer to Section 6.5.2.3.

- Password Bypass = On (default.)
- Modem Passthrough = On (default.)

5.2.1.1. Alternate Configuration for Dial-Up Access to Connected Device:

If your application requires the Password Bypass and Modem Passthrough parameters to be disabled, the following procedure can be used to allow dial-up access to a device connected to the SRM Modem Port:

1. Disable both the Password Bypass and Modem Passthrough parameters as described in Section 6.5.2.3.
2. Dial-in to the SRM unit. When the login prompt appears, enter a valid username and password.
3. When the SRM command prompt appears, type `/C MODEM` and press **[Enter]** to connect to the device that is attached to the SRM Modem Port.
4. When you have finished communicating with the device attached to the SRM, type `^x` (**[Ctrl]** plus **[X]**) to return to SRM command mode. Then type `/x` and press **[Enter]** to exit the modem session.

5.2.2. Network Accessible Shared Modem

The second most common application for the SRM is to serve as a network accessible shared modem. This type of application provides users who do have network access but don't have a modem with network access to the SRM's dial-up functions.

Note: For further instructions regarding configuring SRM Modem parameters, please refer to Section 6.5.2.3.

In order for the SRM to serve as a network accessible, shared Modem, SRM parameters should be set as follows:

- Password Bypass = Off.
- Modem Passthrough = Off.

5.2.2.1. Alternate Configuration for Network Accessible Modem Application

If your application requires the Password Bypass and Modem Passthrough parameters to be enabled, the following procedure can be used to allow the SRM to serve as a network accessible Modem:

1. Enable both the Password Bypass and Modem Passthrough parameters as described in Section 6.5.2.3.
2. Establish a network connection to the SRM unit. When the login prompt appears, enter a valid username and password.
3. When the SRM command prompt appears, type `/D MODEM [Enter]` to disconnect the Modem from the Serial Modem Port.
4. Type `/C MODEM [Enter]` to connect the network port to the SRM's internal Modem. When the connection is established, AT commands can be used to dial-out from the SRM's internal Modem as described in Section 3.4.
5. When you have finished using the Modem, type `/x` and press **[Enter]** to exit from AT command mode. When the SRM command prompt appears, type `/C 2 3` and press **[Enter]** to reconnect the Modem to the Serial Modem Port.

5.2.3. Dial-Up Access to Outbound SSH/Telnet

This application allows users to dial-in to the SRM unit, and then create an outbound SSH or Telnet connection to other devices on the network where the SRM resides. In cases where a device on at a remote site has malfunctioned and disrupted external network communication with the site, an outbound SSH connection initiated via a dial-up connection to the SRM can be used to communicate with the malfunctioning device in order to restore normal operation.

In order for the SRM to provide dial-up access to outbound SSH/Telnet connections at a remote site, SRM parameters should be set as follows:

Note: *For further instructions regarding configuring SRM Modem parameters, please refer to Section 6.5.2.3.*

- Password Bypass = Off.
- Modem Passthrough = Off.

When the Password Bypass and Modem Passthrough parameters disabled, users can dial-in to the SRM unit to access the SRM command mode and then initiate an outbound SSH/Telnet connection as described in Section 9.3 and Section 9.4.

Note: *In order to establish an outbound SSH/Telnet connection, Outbound Access must be enabled for your user account as described in Section 6.4.2. In addition, Telnet Access and Outbound Access must also be enabled via the Network Parameters menu as described in Section 6.6.2.*

5.3. Dialing Commands

When the SRM's AT command mode is active, common AT commands can be used to initiate dial-out operations or change basic Modem configuration parameters as described in Section 3.4.

5.4. Manual Operation

In addition to the command driven functions available via the Web Browser Interface and Text Interface, some SRM functions can also be controlled manually. For a summary of front panel control functions, please refer to Section 2.3.

5.5. Logging Out of Command Mode

When you have finished communicating with the SRM, it is important to always disconnect using either the "LogOut" link (Web Browser Interface) or the /X command (Text Interface), rather than by simply closing your browser window or communications program. When communicating via a mobile device, use the mobile device's "Close" function to disconnect and logout.

When you disconnect using the LogOut link or /X command, this ensures that the SRM has completely exited from command mode, and is not waiting for the inactivity timeout period to elapse before allowing additional connections.

6. Configuration Options

This section describes the basic configuration options for SRM units.

6.1. Configuration Menus

Although the Web Browser Interface and Text Interface (Command Line Interface) provide two separate means for selecting parameters, both interfaces allow access to the same set of basic parameters, and parameters selected via one interface will also be applied to the other. To access the configuration menus, proceed as follows:

- **Text Interface:** Refer to the Help Screen (/H) and then enter the appropriate command to access the desired menu. When the configuration menu appears, key in the number for the parameter you wish to define, and follow the instructions in the resulting submenu.
- **Web Browser Interface:** Use the links and fly-out menus on the left hand side of the screen to access the desired configuration menu. To change parameters, click in the desired field and key in the new value or select a value from a pull-down menu. To apply newly selected parameters, click on the "Change Parameters" button at the bottom of the menu or the "Set" button next to the field.

The following sections describe options and parameters that can be accessed via each of the configuration menus. Please note that essentially the same set of parameters and options are available to both the Web Browser Interface and Text Interface.

Notes:

- *To Access the configuration menus, proceed as described in Section 5.1.*
- *Configuration menus are only available when you have logged into command mode using a password that permits Administrator Level commands. SuperUser accounts are able to view configuration menus, but are not allowed to change parameters.*
- *Configuration menus are not available when you are communicating with the SRM via PDA*
- *When defining parameters via the Text Interface, make certain to press the **[Esc]** key several times to completely exit from the configuration menu and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message has been displayed and the cursor returns to the command prompt.*

6.2. Defining System Parameters

The System Parameters menus are used to define the Site ID Message, set the system clock and calendar, set up data logging functions and calibrate temperature readings. In the Text Interface, the System Parameters menu is also used to create and manage user accounts and passwords. Note however, that when you are communicating with the unit via the Web Browser Interface, accounts and passwords are managed and created using a separate menu that is accessed by clicking on the "Users" link on the left hand side of the menu.

To access the System Parameters menu via the Text Interface, type `/F` and press **[Enter]**. To access the System Parameters menu via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear and then click on the "System Parameters" link. The System Parameters Menus are used to define the following:

- **User Directory:** This function is used to view, add, modify and delete user accounts and passwords. As discussed in Section 6.3 and Section 6.4, the User Directory allows you to set the security level for each account as well as determine which ports each account will be allowed to access.

Note: *The "User Directory" option does not appear in the Web Browser Interface System Parameters menu. In the Web Browser Interface, User accounts are defined via the User Configuration menu, located on the left hand side of the screen.*

- **Site ID:** A text field, generally used to note the installation site or name for the SRM unit. (Up to 64 characters; Default = undefined)

Notes:

- *The Site I.D. will be cleared if the SRM is reset to default settings.*
- *When viewed via the Text Interface (CLI) Site I.D. messages that are over 30 characters long will be truncated. To display the entire Site I.D. message via the Text Interface, type `/J*` and press **[Enter]***
- **Real Time Clock:** This prompt provides access to the Real Time Clock menu, which is used to set the clock and calendar, and to enable and configure the NTP (Network Time Protocol) feature as described in Section 6.2.1.

Note: *The "Real Time Clock" option does not appear in the Web Browser Interface System Parameters menu. In the Web Browser Interface, Real Time Clock parameters are defined via the Real Time Clock submenu, which is accessed via the General Parameters menu.*
- **Invalid Access Lockout:** If desired, this feature can be used to disable serial port access, SSH access, Telnet access and/or Web access to the SRM command mode after a user specified number of unsuccessful login attempts are made. For more information, please refer to Section 6.2.2. (Default = Off)

Note: *The "Invalid Access Lockout" item does not appear in the Web Browser Interface System Parameters menu. In the Web Browser Interface, Invalid Access Lockout parameters are defined via the Serial Port Invalid Access Lockout submenu, which is accessed via the General Parameters menu, located on the left hand side of the screen.*

- **Temperature Format:** Determines whether the temperature is displayed as Fahrenheit or Celsius. (Default = Fahrenheit)
- **Temperature Calibration:** Used to calibrate the unit's internal temperature sensing abilities. To calibrate the temperature, place a thermometer inside your equipment rack, in a location that usually experiences the highest temperature. After a few minutes, take a reading from the thermometer, and then key the reading into the configuration menu. In the Web Browser Interface, the temperature is entered at the System Parameters menu, in the Temperature Calibration field; in the Text Interface, the temperature is entered in a submenu of the System Parameters menu, which is accessed via the Temperature Calibration item. (Default = undefined)
- **Log Configuration:** Configures the Audit Log, Alarm Log and Temperature Log. For more information on event logging functions, please refer to Section 6.2.3. (Default = Audit Log = On without Syslog, Alarm Log = On without Syslog, Temperature Log = On)

Notes:

- *The Alarm Log will create a record of each instance where an Alarm is triggered or cleared at the SRM unit.*
- *The Temperature Log will create a record of ambient rack temperature over time.*
- **Callback Security:** Enables and configures the Callback Security Function as described in Section 6.2.4. In order for this feature to function correctly, a Callback number must also be defined for each desired user account as described in Section 6.4. (Default = On - Callback without Password Prompt, 3 attempts, 30 Minute Delay)

Notes:

- *In the Text Interface, Callback Security Parameters are defined via a submenu of the Systems Parameters Menu, accessed via the Callback Security item.*
- *In the Web Browser Interface, Callback Security Parameters are defined via the Callback Security submenu, which is accessed via the General Parameters menu, located on the left hand side of the screen.*
- **Front Panel Buttons:** This item can be used to disable all front panel button functions. (Default = On)
- **Modem Phone Number / IP Address:** This parameter can be used to record the phone number for the modem. In cases where the SRM application includes a cellular modem, the IP address for the cellular modem can be entered via this parameter (Default = undefined)

- **Scripting Options:** Provides access to parameters that are used to set up the SRM unit for running various scripts as described in Section 6.2.5.

Notes:

- *The functions provided by the Scripting Options menu are intended for use in applications where scripts are employed to control SRM operation. Improper use of Scripting Options menu functions can cause the SRM unit to become unresponsive. Prior to attempting to use the functions provided by the Scripting Options menu, please contact WTI Technical Support as described in Appendix C in this User's Guide.*
- *In the Text Interface, the Scripting Options submenu is accessed via item 12. To access the Scripting Options parameters via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear, then click on the "Scripting Options" link.*
- **Asset Tag:** Allows a descriptive tag or tracking number to be assigned to the SRM unit. Once defined, the Asset Tag can be displayed via the Product Status Screen in the Web Interface or via the `/J*` command in the Text Interface. (Default = Undefined)
- **Login Banner:** Allows definition of a banner/message that will be displayed when a valid username and password are entered during log in. The Login Banner can be used to post legal warning regarding unauthorized access to the unit or to display other user-defined information or instructions. (Default = Undefined)

Notes:

- *Although the Login Banner will be displayed when the SRM is accessed via both the Text Interface and Web Browser Interface, the Login Banner can only be defined via the Text Interface.*
- *The Login Banner can be up to 1024 characters long.*
- *The Login Banner text must begin with the `<banner>` command and end with the `</banner>` command.*
- *Banner text can be copied and pasted from a text editor, or sent in from a file.*
- *For best results, the individual text lines in the Login Banner should be less than 80 characters wide.*

6.2.1. The Real Time Clock and Calendar

The Real Time Clock menu is used to set the SRM's internal clock and calendar. The configuration menu for the Real Time Clock offers the following options:

- **Date:** Sets the Month, Date, Year and day of the week.
- **Time:** Sets the Hour, Minute and Second for the SRM's real time clock/calendar. Key in the time using the 24-hour (military) format.
- **Time Zone:** Sets the time zone, relative to Greenwich Mean Time. Note that the Time Zone setting will function differently, depending upon whether or not the NTP feature is enabled and properly configured. (Default = GMT (No DST))
 - ◆ **NTP Enabled:** The Time Zone setting is used to adjust the Greenwich Mean Time value (received from the NTP server) in order to determine the precise local time for the selected time zone.
 - ◆ **NTP Disabled:** If disabled, or if the unit cannot access the NTP server, then status screens and activity logs will list the selected Time Zone and Real Time Clock value, but will not apply the correction factor to the Real Time Clock value.
- **NTP Enable:** When enabled, the SRM will contact an NTP server (defined via the NTP Address prompts) once a day, and update its clock based on the NTP server time and selected Time Zone. (Default = Off)

Notes:

- *The SRM will also contact the NTP server and update the time whenever you change NTP parameters.*
- *To cause SRM to immediately contact the NTP server at any time, make certain that the NTP feature is enabled and configured, then type `/F` and press **[Enter]**. When the System Parameters menu appears, press **[Esc]**. The SRM will save parameters and then attempt to contact the server, as specified by currently defined NTP parameters.*
- **Primary NTP Address:** Defines the IPv4 and/or IPv6 protocol IP address or domain name for the primary NTP server. (Default = undefined)

Notes:

- *In order to use domain names for web addresses, DNS Server parameters must first be defined as described in Section 6.6.5.*
- *The Web Browser Interface includes two separate fields that are allowed to define both an IPv4 protocol and IPv6 protocol format Primary NTP Address and Secondary NTP Address.*
- *When the Primary NTP Address and Secondary NTP Address are defined via the Text Interface, the SRM will display a prompt that instructs the user to select IPv4 or IPv6 protocol.*
- *The SRM allows parameters for both IPv4 and IPv6 protocols to be defined and saved.*

- **Secondary NTP Address:** Defines the IPv4 and/or IPv6 protocol IP address or domain name for the secondary, fallback NTP Server. (Default = undefined)

Notes:

- *In order to use domain names for web addresses, DNS Server parameters must first be defined as described in Section 6.6.5.*
 - *The Web Browser Interface includes two separate fields that are allowed to define both an IPv4 protocol and IPv6 protocol format Primary NTP Address and Secondary NTP Address.*
 - *When the Primary NTP Address and Secondary NTP Address are defined via the Text Interface, the SRM will display a prompt that instructs the user to select IPv4 or IPv6 protocol.*
 - *The SRM allows parameters for both IPv4 and IPv6 protocols to be defined and saved.*
- **NTP Timeout:** The amount of time in seconds, that will elapse between each attempt to contact the NTP server. When the initial attempt is unsuccessful, the SRM will retry the connection four times. If neither the primary nor secondary NTP server responds, the SRM will wait 24 hours before attempting to contact the NTP server again. (Default = 3 Seconds)
- **Test NTP Servers:** Allows you to ping the IP addresses or domain names defined via the Primary and Secondary NTP Address prompts, or to ping a new address or domain defined via the Test NTP Servers submenu in order to check that a valid IP address or domain name has been entered.

Notes:

- *In order for the Test NTP Servers feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Test NTP Servers option, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

6.2.2. The Serial Port Invalid Access Lockout Feature

When properly configured and enabled, the Invalid Access Lockout feature can watch all login attempts made via SSH connection, Telnet connection, web browser or the serial SetUp Port. If the counter for any of these exceeds the user-defined threshold for maximum invalid attempts, then the SetUp port or protocol used will be automatically disabled for the length of time specified by the Lockout Duration parameter.

When Invalid Access Attempt monitoring is enabled for the serial SetUp Port, the SRM will count invalid access attempts at the serial SetUp Port. If the number of invalid access attempts exceeds the defined Lockout Attempts trigger value, the SRM will lock the serial SetUp Port for the defined Lockout Duration period. When Invalid Access Attempt monitoring for SSH, Telnet or Web are selected, a lockout will be triggered when the number of invalid access attempts during the defined Lockout Duration period exceeds the defined Hit Count for the protocol. For example, if the SSH Hit Count is set at 10 and the SSH Lockout Duration period is set at 120 seconds, then if over 10 invalid access attempts are detected within 120 seconds, the SRM will then lock out the MAC address that generated the excessive attempts for 120 seconds.

Note that when an Invalid Access Lockout occurs, you can either wait for the Lockout Duration period to elapse (after which, the SRM will automatically reactivate the port or protocol), or you can issue the /UL command (type /UL and press **[Enter]**) via the Text Interface to instantly unlock all SRM logical network ports and communication protocols.

Notes:

- *When the Serial Port Invalid Access Lockout Alarm has been enabled as described in Section 7.3, the SRM can also provide notification via email, Syslog Message, and/or SNMP trap whenever an Invalid Access Lockout occurs at the serial port.*
- *If the Network Port has been locked by the Invalid Access Lockout feature, it will still respond to the ping command (providing that the ping command has not been disabled at the Network Port.)*

The Invalid Access Lockout configuration menus allow you to select the following parameters:

- **Serial Port Protection (Serial Port Lockout):** Enables/Disables the Invalid Access Lockout function for the serial SetUp Port and selects lockout parameters. When this item is enabled and excessive Invalid Access attempts are detected at the SetUp Port, the SetUp Port will be locked until the user-defined Lockout Duration period elapses, or until the /UL command is issued.
- **Serial Port Protection:** Enables/Disables the Invalid Access Lockout feature for the serial SetUp Port. (Default = Off)
- **Lockout Attempts:** The number of invalid attempts that must occur in order to trigger the Invalid Access Lockout feature at the serial SetUp Port. (Default = 9)
- **Lockout Duration:** This option selects the length of time that the serial SetUp Port will remain locked when Invalid Access Lockout occurs. If the duration is set at "Infinite", then ports will remain locked until the /UL command is issued. (Default = 30 Minutes)

- **SSH Protection:** Enables/Disables and configures the Invalid Access function for SSH connections. When this item is enabled and excessive Invalid Access Attempts via SSH are detected, then the SRM will lock out the offending MAC address for the user-defined SSH Lockout Duration Period or until the /UL command is issued. Note that for SSH protection, the lockout trigger is a function of the SSH Hit Count parameter and the SSH Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for SSH connections. (Default = Off)
- **SSH Hit Count:** The number of invalid attempts that must occur during the length of time specified by the SSH Lockout Duration period in order to trigger the Invalid Access Lockout feature for SSH protocol. For example, if the SSH Hit Count parameter is set to 10 and the SSH Lockout Duration parameter is set to 30 minutes, then the SRM will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 20)
- **SSH Lockout Duration:** This option selects both the length of time that an SSH Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When an SSH Lockout occurs, the offending MAC address will be prevented from establishing an SSH connection to the SRM for the defined SSH Lockout Duration period. (Default = 2 Seconds)
- **Telnet Protection:** Enables/Disables and configures the Invalid Access function for Telnet connections. When this item is enabled and excessive Invalid Access Attempts via Telnet are detected, then the SRM will lock out the offending MAC address for the user-defined Telnet Lockout Duration Period or until the /UL command is issued. Note that for Telnet protection, the lockout trigger is a function of the Telnet Hit Count parameter and the Telnet Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for Telnet connections. (Default = Off)
- **Telnet Hit Count:** The number of invalid attempts that must occur during the length of time specified by the Telnet Lockout Duration period in order to trigger the Invalid Access Lockout feature for the Telnet protocol. For example, if the Telnet Hit Count parameter is set to 10 and the Telnet Lockout Duration parameter is set to 30 minutes, then the SRM will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 20)
- **Telnet Lockout Duration:** This option selects both the length of time that a Telnet Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When a Telnet Lockout occurs, the offending MAC address will be prevented from establishing a Telnet connection to the SRM for the defined Telnet Lockout Duration period. (Default = 2 Seconds)

- **Web Protection:** Enables/Disables and configures the Invalid Access function for Web connections. When this item is enabled and excessive Invalid Access Attempts via Web are detected, then the SRM will lock out the offending MAC address for the user-defined Web Lockout Duration Period or until the /UL command is issued. Note that for Web protection, the lockout trigger is a function of the Web Hit Count parameter and the Web Lockout Duration Parameter.
- **Lockout Enable:** Enables/Disables Invalid Access Lockout protection for web connections. (Default = Off)
- **Web Hit Count:** The number of invalid attempts that must occur during the length of time specified by the Web Lockout Duration period in order to trigger the Invalid Access Lockout feature for Web access. For example, if the Web Hit Count parameter is set to 10 and the Web Lockout Duration parameter is set to 30 minutes, then the SRM will lock out the offending MAC address for 30 minutes when over 10 invalid access attempts occur during any 30 minute long period. (Default = 20)
- **Web Lockout Duration:** This option selects both the length of time that a Web Lockout will remain in effect and also the time period over which invalid access attempts will be counted. When a Web Lockout occurs, the offending MAC address will be prevented from establishing a Web connection to the SRM for the defined Telnet Lockout Duration period. (Default = 2 Seconds)

6.2.3. Log Configuration

This feature allows you to create records of command activity, alarm actions and temperature readings for the SRM unit. The Log features are enabled and configured via the System Parameters Menu. The SRM features three different event logs: the Audit Log, the Alarm Log and the Temperature Log:

- **Audit Log:** Creates a record of user activity. In addition, the Audit Log also includes login/logout records for all users and connection/disconnection records for the serial ports. Each Log record includes a description of the activity, the username for the account that initiated the action and the time date that each event occurred.
- **Alarm Log:** Creates a record of all Alarm Activity at the SRM unit. Each time an alarm is triggered or cleared, the SRM will generate a record that lists the time and date of the alarm, the name of the Alarm triggered, a description of the Alarm and the time and date that the Alarm was cleared.
- **Temperature Log:** Provides a record of temperature levels over time at the unit. Each Log record will include the time and date, and the temperature reading.

6.2.3.1. The Audit Log and Alarm Log Configuration Options

The System Parameters menu allows you to select three different configuration parameters for the Audit Log and Alarm Log. Note that the Audit and Alarm Logs function independently, and parameters selected for one will not be applied to the other.

- **Off:** The Log is disabled; command activity and/or alarm events will not be logged.
- **On - With Syslog:** The Log is enabled and the SRM will generate a Syslog Message every time a Log record is created.
- **On - Without Syslog:** The Log is enabled, but the SRM will not generate a Syslog Message every time a Log record is created. (Default Setting)

Notes:

- *In order for the Audit Log or Alarm Log to generate Syslog Messages, Syslog Parameters must first be defined as described in Section 10.*
- *The Audit Log will truncate usernames that are longer than 22 characters, and display two dots (..) in place of the remaining characters.*

6.2.3.2. The Temperature Log

The System Parameters menu allows you to either enable or disable the Temperature Log. When the Temperature Log is disabled, the SRM will not log temperature readings. In the default state, the Temperature Log is enabled.

6.2.3.3. Reading, Downloading and Erasing Logs

To read or download the status logs, proceed as follows:

- **Text Interface:** Type **/L** and press **[Enter]** to access the Display Log menu. Key in the number for the desired option, press **[Enter]**, and then follow the instructions in the resulting submenu.
- **Web Browser Interface:** Move the cursor over the "Logs" link on the left hand side of the screen. When the flyout menu appears, click on the desired "Download" or "Display" option.

To erase log data, access command mode via the Text Interface, using an account that permits Administrator level commands, then type **/L** and press **[Enter]** to access the Display Logs menu and proceed as follows:

- **Audit Log:** At the Display Logs menu, key in the number for the Audit Log option and press **[Enter]**. When the Audit Log menu appears, key in the number for the Erase function, press **[Enter]** and follow the instructions in the resulting submenu.
- **Alarm Log:** At the Display Logs menu, key in the number for the Alarm Log option and press **[Enter]**. When the Alarm Log menu appears, key in the number for the Erase function, press **[Enter]** and follow the instructions in the resulting submenu.
- **Temperature Log:** At the Display Logs menu, key in the number for the Temperature Log option and press **[Enter]**. When the Temperature Log menu appears, key in the number for the Erase function, press **[Enter]** and follow the instructions in the resulting submenu.

Notes:

- *The SRM dedicates a fixed amount of internal memory for Audit Log records, and if log records are allowed to accumulate until this memory is filled, memory will eventually "wrap around," and older records will be overwritten by newer records.*
- *Note that once records have been erased, they cannot be recovered.*

6.2.4. Callback Security

The Callback function provides an additional layer of security when users attempt to access the SRM's command mode via modem. When this function is properly configured, modem users will not be granted immediate access to command mode upon entering a valid password; instead, the unit will disconnect, and dial a user-defined number before allowing access via that number. If desired, users may also be required to re-enter the password *after* the SRM dials back.

In order for Callback Security to function properly, you must first enable and configure the feature as described in this section, and then define a callback number for each desired user account as described in Section 6.4.

To access the Callback Security menu via the Text Interface, type `/F` and press **[Enter]** and then select the Callback Security option. To access the Callback Security menu via the Web Browser Interface, place the cursor over the General Parameters link, wait for the flyout menu to appear, and then Click on the "Callback Security" link. In both the Text Interface and Web Browser Interface, the Callback Security Menu offers the following options:

- **Callback Enable:** This prompt offers five different configuration options for the Callback Security feature: (Default = On - Callback (Without Password Prompt))
 - ◆ **Off:** All Callback Security is disabled.
 - ◆ **On - Callback (Without Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the login prompt will *not* be displayed when the user's modem answers. If the account *does not* include a Callback Number, that user will be granted immediate access and a Callback will *not* be performed.
 - ◆ **On - Callback (With Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the login prompt *will* be displayed when the user's modem answers (accounts that include a Callback Number will be required to re-enter their username/password when their modem answers.) If the account *does not* include a Callback Number, then that user will be granted immediate access and a Callback will *not* be performed.
 - ◆ **On - Callback ONLY (Without Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the username/password prompt will *not* be displayed when the user's modem answers. Accounts that *do not* include a Callback Number will *not* be able to access command mode via modem.
 - ◆ **On - Callback ONLY (With Password Prompt):** Callbacks will be performed for user accounts that include a Callback Number, and the username/password prompt *will* be displayed when the user's modem answers (users will be required to re-enter their username/password when their modem answers.) Accounts that *do not* include a Callback Number will *not* be able to access command mode via modem.
- **Callback Attempts:** The number of times that the SRM will attempt to contact the Callback number. (Default = 3 attempts)

- **Callback Delay:** The amount of time that the SRM will wait between Callback attempts. (Default = 30 seconds)

Notes:

- *After configuring and enabling Callback Security, you must then define a callback phone number for each desired user account (as described in Section 6.4) in order for this feature to function properly.*
- *When using the "On - Callback (With Password Prompt)" option, it is important to remember that accounts that do not include a callback number will be allowed to access command mode without callback verification.*

6.2.5. Scripting Options

The Scripting Options submenu provides access to parameters that are used to set up the SRM unit for running various scripts.

Notes:

- *The functions provided by the Scripting Options menu are intended for use in applications where scripts are employed to control SRM operation. Improper use of Scripting Options menu functions can cause the SRM unit to become unresponsive. Prior to attempting to use the functions provided by the Scripting Options menu, please contact WTI Technical Support as described in Appendix C in this User's Guide.*
- *To access Scripting Options parameters via the Text Interface, first type `/F` and press **[Enter]** to display the System Parameters Menu, then key in the number for the Scripting Options item and press **[Enter]**.*
- *To access the Scripting Options parameters via the Web Browser Interface, place the cursor over the "General Parameters" link, wait for the flyout menu to appear, then click on the "Scripting Options" link.*

The Scripting Options menu allows the following parameters to be defined:

- **Command Prompt:** Allows the Text Interface command prompt to be set to either SRM, RSM, TSM or the currently defined Site I.D. Message. (Default = SRM)
- **TCP Hold Write Options:** These options can be used to minimize the number of data packets that are sent from the SRM unit. In cases where the SRM is receiving a slow flow of data from an attached device, the TCP Hold Write Options can be configured to set the size of each packet and define a maximum "hold" time in order to determine how long data is allowed to accumulate in the buffer before being sent.
- **TCP Hold Write Enable:** Enables/disables the TCP Hold Write function. (Default = Off)
- **TCP Hold Write Duration:** Determines the maximum amount of time (in 40 msec intervals) that data will be allowed to accumulate before transmission. (Default = 2)
- **TCP Hold Write Buffer Size:** Determines the size of the TCP Hold Write Buffer. When the amount of accumulated data reaches the currently defined Hold Write Buffer Size, buffered data will be sent. (Default = 512 Characters)

- **Reverse DNS:** Determines the manner in which ARP requests are handled. When enabled (On,) the unit will check an external DNS in order to resolve domain names. When disabled (Off,) the unit will not check an external DNS when resolving domain names. (Default = On)
- **Port 1 Mode Override:** In order to ensure local access to SRM command functions, normally the SetUp Port can only be configured as a Passive Mode Port or Any-to-Any Mode Port. When the Port 1 Mode Override option is enabled, the SetUp Port can be configured as a Buffer Mode Port, Modem Mode Port or Modem PPP Port. (Default = Off)

Note: *Configuring the SetUp as a Buffer Mode Port can lead to a situation where local access to SRM command functions is not available via serial port.*

- **USB State:** Enables/Disables the USB Mini format SetUp Port. (Default = On)
- **Reboot Unit:** (Web Interface Only) Restarts the SRM unit's operating system. To restart the SRM unit via the text interface, invoke the `/I` command as described in Section 15.

Note: *The Reboot function that is provided via the Scripting Options menu and `/I` command does not switch off power to the SRM unit. The reboot function only restarts the SRM's operating system.*

6.3. User Accounts

Each time you attempt to access command mode, you will be prompted to enter a username (login) and password. The username and password entered at login determine which serial port(s) you will be allowed to access and what type of commands you will be allowed to invoke. Each username / password combination is defined within a "user account."

The SRM allows up to 128 user accounts; each account includes a username, password, command access level, port access rights, service access rights and an optional callback number.

6.3.1. Command Access Levels

In order to restrict access to important command functions, the SRM allows you to set the command access level for each user account. The SRM offers four different access levels: Administrator, SuperUser, User and View Only. Command privileges for each user account are set using the Add User or Modify User menus.

Each access level grants permission to use a different selection of commands; lower access levels are restricted from invoking configuration commands, while Administrators are granted access to all commands. The four access levels are described below:

- **Administrator:** Administrators are allowed to invoke all configuration and operation commands, can view all status screens and connect to all ports.
- **SuperUser:** SuperUsers are allowed to invoke all port connection commands and view all status screens. SuperUsers can view configuration menus, but are not allowed to change configuration parameters. SuperUsers are granted access to all serial ports.
- **User:** Users are allowed to invoke port connection commands and view all status screens, but can only apply commands to the ports that they have been specifically granted access to. Users are not allowed to view configuration menus or change configuration parameters.
- **ViewOnly:** Accounts with ViewOnly access, are allowed to view Status Menus, but are not allowed to invoke port connection commands, and cannot view configurations menus or change parameters. ViewOnly accounts can display status screens, but can only view the status of ports that are allowed by the account.

Section 15.2 summarizes command access for all four access levels.

In the default state, the SRM includes one predefined account that provides access to Administrator commands and allows to control of all of the SRM's serial ports. The default username for this account is "**super**" (lowercase, no quotation marks), and the password for the account is also "**super**".

Notes:

- *In order to ensure security, it is recommended that when initially setting up the unit, a new user account with Administrator access should be created, and the default "super" account should then be deleted.*
- *If the SRM is reset to default parameters, all user accounts will be cleared, and the default "super" account will be restored.*

6.3.2. Granting Serial Port Access

Each account can be granted access to a different selection of ports. Note also, that several accounts can be allowed access to the same port. When accounts are created, the Port Access parameter in the Add User or Modify User menu can be used to grant or deny access to each serial port by that account.

In addition, each command access level is also used to restrict the serial ports that the account will be allowed to access:

- **Administrator:** Accounts with Administrator access are always allowed to control all Serial Ports. Port access cannot be disabled for Administrator level accounts.
- **SuperUser:** SuperUser accounts allow access to all Serial Ports. Port access cannot be disabled for SuperUser level accounts.
- **User:** Accounts with User level access are only allowed to create connections with the Serial Ports that have been specifically permitted via the "Port Access" parameter in the Add User and Modify User menus.
- **ViewOnly:** Accounts with ViewOnly access are not allowed to create connections with Serial Ports. ViewOnly accounts can display the status of Serial Ports, but are limited to the ports specified by the account.

6.4. Managing User Accounts

The User Directory function is employed to create new accounts, display parameters for existing accounts, modify accounts and delete accounts. Up to 128 different user accounts can be created. The "User Directory" function is only available when you have logged into command mode using an account that permits Administrator commands.

In both the Text Interface and the Web Browser Interface, the user configuration menu offers the following functions:

- **View User Directory:** Displays currently defined parameters for any SRM user account as described in Section 6.4.1.
- **Add Username:** Creates new user accounts, and allows you to assign a username, password, command level, access rights and callback number, as described in Section 6.4.2.
- **Modify User Directory:** This option is used to edit or change account information, as described in Section 6.4.3.
- **Delete User:** Clears user accounts, as described in Section 6.4.4.

Note: After you have finished selecting or editing account parameters, make certain to save the new account information before proceeding. In the Web Browser Interface, click on the "Add User" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the SRM displays the "Saving Configuration" message and the cursor returns to the command prompt.

6.4.1. Viewing User Accounts

The "View User Directory" option allows you to view details about each account. The View User option will not display actual passwords, and instead, the password field will read "defined". The View User Accounts function is only available when you have accessed command mode using a password that permits Administrator Level commands.

6.4.2. Adding User Accounts

The "Add Username" option allows you to create new accounts. Note that the Add User function is only available when you have accessed command mode using a password that permits Administrator Level commands. The Add User Menu can define the following parameters for each new account:

- **Username:** Up to 32 characters long, and cannot include non-printable characters. Duplicate usernames are not allowed. (Default = undefined)
- **Password:** Five to 16 characters long, and cannot include non-printable characters. Note that passwords are case sensitive. (Default = undefined)
- **Access Level:** Determines which commands this account will be allowed to access. This option can set the access level for this account to "Administrator", "SuperUser", "User" or "ViewOnly." For more information on Command Access Levels, please refer to Section 6.3.1 and Section 15.2. (Default = User)

- **Port Access:** Determines which SRM Serial Ports this account will be allowed to access. (Defaults; Administrator & SuperUser = All Ports On, User and ViewOnly = undefined)

Notes:

- *Administrator and SuperUser level accounts will always have access to all Serial Ports.*
 - *ViewOnly accounts are allowed to display the status of Serial Ports, but are limited to the ports specified by the account. ViewOnly accounts are not allowed to create connections between ports.*
 - *The Port Access parameter is also used to grant or deny user access to the modem port.*
- **Service Access:** Determines whether this account will be able to access command mode via Serial Port, Telnet/SSH or Web and whether or not the account will be allowed to initiate outbound connections. For example, if Telnet/SSH Access is disabled for this account, then this account will not be able to access command mode via Telnet or SSH. (Default = Serial Port = On, Telnet/SSH = On, Web = On, Outbound Access = Off.)

Note: *The Service Access Parameter is only used to select permitted access services for an individual user account. To separately enable/disable all SSH or Telnet Access for the SRM unit, please refer to Section 6.6.2.*

- **Callback Phone Number:** Assigns a number that will be called when this account attempts to access command mode via modem, and the Callback Security Function has been enabled as described in Section 6.2.4. (Default = undefined)

Notes:

- *If the Callback Phone Number is not defined, then Callbacks will not be performed for this user.*
- *If the Callback Phone Number is not defined for a given user, and the Callback Security feature is configured to use either of the "On - Callback" options, then this user will be granted immediate access to command mode via modem.*
- *If the Callback Phone Number is not defined for a given user, and the Callback Security feature is configured to use the "On - Callback ONLY" option, then this user will not be able to access command mode via Modem.*
- *When using the "On - Callback (With Password Prompt)" option, it is important to remember that accounts that do not include a callback phone number will be allowed to access command mode without callback verification.*

- **Authorization Keys:** This item can be used to assign an SSH Authorization Key to the user account, view assigned authorization keys or delete assigned authorization keys. When a valid authorization key is assigned to a given user, that user will be able to access SRM command mode without entering a password. When assigning an authorization key, the SRM offers the option to define a name for the key and upload a key from the user's server.

Note: *After you have finished selecting or editing account parameters, make certain to save the new account information before proceeding. In the Web Browser Interface, click on the "Add User" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the SRM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

6.4.3. Modifying User Accounts

The "Modify User Directory" function allows you to edit existing user accounts in order to change parameters, port access rights or Administrator Command capability. Note that the Modify User function is only available when you have entered command mode using a password that permits Administrator Level commands. Once you have accessed the Modify Users menu, use the menu options to redefine parameters in the same manner that is used for the Add User menu, as discussed in Section 6.4.2.

Note: *After you have finished changing parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify User" button to save parameters; in the Text Interface, press the **[Esc]** key several times until the SRM displays the "Saving Configuration" message.*

6.4.4. Deleting User Accounts

This function is used to delete individual user accounts. Note that the Delete User function is only available when you have accessed command mode using a password that permits Administrator Level commands.

Notes:

- *Deleted accounts cannot be automatically restored.*
- *The SRM allows you to delete the default "super" account, which is included to permit initial access to command mode. Before deleting the "super" account, make certain to create another account that permits Administrator Access. If you do not retain at least one account with Administrator Access, you will not be able to invoke Administrator level commands.*

6.5. Modem and Serial Port Configuration

The Serial Port Configuration menus allow you to select parameters for the SRM's serial RJ45 SetUp Port, Modem Port and internal modem. When responding to prompts, invoking commands, and selecting items from port configuration menus, note the following:

Notes:

- *Configuration menus are only available to Administrator level accounts.*
- *Providing that the Port 1 Override Mode is not enabled, the SetUp port (Port 1) will always be configured for Any-to-Any Mode.*
- *The Serial Modem Port (Port 2) will always be configured for Passive Mode.*
- *For a description of the procedure for configuring the USB Mini Port, please refer to Section 6.6.1.*
- *If you intend to use the SRM solely for inbound Modem communication, in most cases there is no need to change serial port parameters; the default configuration will work well for most Modem communication applications.*

6.5.1. Modem Modes

The SRM's internal modem can be set to two different operation modes:

- **Modem Mode:** Allows communication between connected ports and permits access to command mode. Modem Mode allows definition of a Hang-Up String, Reset String, Initialization String and other modem-related parameters. The Modem Mode is the default mode for the SRM's internal Modem.
- **Modem PPP Mode:** Allows data that is normally sent via ethernet to be sent via phone line. The Modem PPP allows definition of a Hang-Up String, Reset String, Initialization String, IP Address and other communication-related parameters..

For more information on Port Modes, please refer to Section 15.2.

6.5.2. The Serial Port Configuration Menus

To configure the SRM's serial SetUp Port, Modem Port or internal modem via the Text Interface, access the SRM's command mode using an account that allows Administrator level commands and then proceed as follows:

- **Serial SetUp Port:** Type /P 1, press [Enter] and then proceed as described in Section 6.5.2.1.
- **Serial Modem Port:** Type /P 2, press [Enter] and then proceed as described in Section 6.5.2.2.
- **Internal Modem:** Type /P 3, press [Enter] and then proceed as described in Section 6.5.2.3.

To configure the Serial Ports via the Web Browser Interface, access the SRM's command mode using an account that permits Administrator level commands and then click on the "Serial Port Configuration" link on the left hand of the screen. When the port selection menu appears, select either the SetUp Port, Modem Port or Modem, click on the "Select Port" button and then proceed as described in Sections 6.5.2.1, 6.5.2.2 or 6.5.2.3.

6.5.2.1. Serial SetUp Port Parameters

The Serial Port Configuration menu allows the following parameters to be defined for the Serial SetUp Port.

Note: *Parameters defined for the Serial SetUp Port will not be applied to the USB Mini SetUp Port. To define parameters for the USB Mini SetUp Port, please refer to Section 6.6.1.*

Communication Settings:

- **Baud Rate:** Any standard rate from 300 bps to 460K bps. (Defaults = 9600 bps)
- **Bits/Parity:** (Default = 8-None)
- **Stop Bits:** (Default = 1)
- **Handshake Mode:** XON/XOFF, RTS/CTS (hardware), Both, or None. (Default = RTS/CTS)

General Parameters:

- **Logoff Character:** The Logoff Character determines the command(s) or character(s) that must be issued at this port in order to disconnect. (Default = ^x)
- **Sequence Disconnect:** Enables/Disables and configures the Resident Disconnect command. This offers the option to disable the Sequence Disconnect, select a one character format or a three character format. (Default = One Character)
- **Inactivity Timeout:** Enables and selects the Timeout Period for this port. If enabled, the Serial Port will disconnect when no additional data activity is detected for the duration of the timeout period. (Default = 5 Minutes)

6.5.2.2. Serial Modem Port Parameters

The Serial Port Configuration menu allows the following parameters to be defined for the Serial Modem Port.

Note: *Parameters defined for the Serial SetUp Port will not be applied to both the RJ45 Serial Modem Port and the DB25 Serial Modem Port.*

Communication Settings:

- **Baud Rate:** Any standard rate from 300 bps to 460K bps. (Defaults = 9600 bps)
- **Bits/Parity:** (Default = 8-None)
- **Stop Bits:** (Default = 1)
- **Handshake Mode:** XON/XOFF, RTS/CTS (hardware), Both, or None. (Default = RTS/CTS)

6.5.2.3. Internal Modem Parameters

The Serial Port Configuration menu allows the following parameters to be defined for the Internal Modem.

Communication Settings:

- **Baud Rate:** Any standard rate from 300 bps to 460K bps. (Defaults = 9600 bps)
- **Bits/Parity:** (Default = 8-None)
- **Stop Bits:** (Default = 1)
- **Handshake Mode:** XON/XOFF, RTS/CTS (hardware), Both, or None. (Default = RTS/CTS)

General Parameters:

- **Logoff Character:** The Logoff Character determines the command(s) or character(s) that must be issued at this port in order to disconnect. (Default = ^x)
- **Sequence Disconnect:** Enables/Disables and configures the Resident Disconnect command. This offers the option to disable the Sequence Disconnect, select a one character format or a three character format. (Default = One Character)
- **Inactivity Timeout:** Enables and selects the Timeout Period for this port. If enabled, the Serial Port will disconnect when no additional data activity is detected for the duration of the timeout period. (Default = 5 Minutes)
- **Password Bypass:** Suppresses the password prompt for the internal modem. (Default = On)
- **Modem Passthrough:** Enables/disables the Modem Passthrough Mode. (Default = On)

Modem Parameters:

- **Port Mode:** Sets the operation mode for the internal modem to either Modem Mode (standard modem mode) or Modem PPP Mode. (Default = Modem Mode)

Depending on the Port Mode selected, the SRM will also display the additional prompts listed below. In the Text Interface, these parameters are accessible via a submenu, which will only be active when the appropriate port mode is selected. In the Web Browser Interface, fields will be "grayed out" unless the corresponding port mode is selected.

- ◆ **Modem Mode:** Permits access to command mode and simplifies connection to an external modem. Modem Mode ports can perform all functions normally available in Any-to-Any Mode, but Modem Mode also allows definition of a Hang-Up String, Reset String, and Initialization String:
 - **Modem Initialization String:** Defines a command string that can be sent to initialize a modem to settings required by your application. (Default = `ATE0M0Q1S0=1`)
 - **'E' Echo Commands:** Enables/disables the internal Modem's command echo function. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = No Echo)
 - **'M' Monitor Speaker:** Enables/disables the internal Modem's speaker. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = Speaker Always OFF)
 - **'Q' Quiet Mode:** Enables/disables the internal Modem's result code/command response function. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = Disable Result Codes / Command Response)
 - **'S0=' Rings Until Answer:** Determines when the Modem will pick up an incoming call (rings to answer.) For example, if this value is set to one, then the modem will pick up an incoming call on the second ring. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = 1 Ring(s) Until Answer)
 - **Default Modem Init. String:** Resets the Modem Initialization String to the default value.
 - **Reset/No Dialtone Interval:** Determines how often the Reset String will be sent and also sets the trigger value for the No Dialtone Alarm. For more information on the No Dialtone Alarm, please refer to Section 7.5. (Default = 15 Minutes)
 - **No Dialtone Alarm Enable:** When this item is "On" the No Dialtone Alarm can be enabled as described in Section 7.5. When the No Dialtone Alarm is enabled, the SRM will monitor the phone line connected to the modem and generate an alarm when no dialtone is detected for the duration of the currently defined Reset/No Dial Tone Interval value. (Default = On)

- ◆ **Modem PPP Mode:** Allows data that is normally sent via ethernet to be sent via phone line. When Modem PPP Mode is selected, the following modem-related parameters will be available:
 - **Modem Initialization String:** Defines a command string that is used to initialize the modem to settings required for PPP communication (Default = `ATQ0V1E1S0=0&C1&D2`)
 - **'E' Echo Commands:** Enables/disables the internal Modem's command echo function. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = Echo On)
 - **'M' Monitor Speaker:** Enables/disables the internal Modem's speaker. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = Speaker ON Until Carrier Detected)
 - **'Q' Quiet Mode:** Enables/disables the internal Modem's result code/command response function. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = Enable Result Codes / Command Response)
 - **'S0=' Rings Until Answer:** Determines when the Modem will pick up an incoming call (rings to answer.) For example, if this value is set to one, then the modem will pick up an incoming call on the second ring. Note that when the setting for this parameter is changed, the Modem Initialization String will also be changed to reflect the new status of this parameter. (Default = No Answer)
 - **Default Modem Init. String:** Resets the Modem Initialization String to the default value.
 - **Reset/No Dialtone Interval:** Determines how often the Reset String will be sent and also sets the trigger value for the No Dialtone Alarm. For more information on the No Dialtone Alarm, please refer to Section 7.5. (Default = 15 Minutes)
 - **No Dialtone Alarm Enable:** When this item is "On" the No Dialtone Alarm can be enabled as described in Section 7.5. When the No Dialtone Alarm is enabled, the SRM will monitor the phone line connected to the modem and generate an alarm when no dialtone is detected for the duration of the currently defined Reset/No Dial Tone Interval value. (Default = On)

➤ **Modem PPP Parameters:** (Text Interface Only) In the Text Interface, this option provides access to a submenu that is used to define the following parameters. In the Web Browser Interface, these parameters are included in the Modem Parameters Menu.

◆ **Periodic Reset Location:** The IP address or URL for the website that will be used to keep the PPP connection alive when not in use. The SRM will regularly ping the selected IP address or URL in order to keep the connection alive. (Default = undefined)

Notes:

- *In order to select a domain name as the Periodic Reset Location, you must first define the Domain Name Servers as described in Section 6.6.5.*
- *The IP Address, P-t-P and Subnet Mask parameters cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication is started..*

◆ **PPP Phone Number:** The phone number for the line that will be used for PPP communication. (Default = undefined)

◆ **Username:** The user name for the ISP account that will be used for PPP communication. (Default = undefined)

◆ **Password:** The password for the ISP count that will be used for PPP communication (Default = undefined)

◆ **IP Address:** The temporary IP address that will be assigned to the PPP communication session by the ISP. Note that this item cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication session is started. (Default = undefined)

◆ **P-t-P:** Note that this item cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication session is started. (Default = undefined)

◆ **Subnet Mask:** Note that this item cannot be defined by the user and will be automatically supplied by the ISP when a PPP communication session is started. (Default = undefined)

6.6. Network Configuration

The Network Parameters Menus are used to select parameters and options for the Network Port and also allow you to implement various security and authentication features. To access the Network Parameters menus, proceed as described in the pages that follow.

Although the Web Browser Interface and Text Interface allow definition of essentially the same network parameters, parameters are arranged differently in the two interfaces. In the Text Interface, most network parameters are defined via a single menu. But in the Web Browser Interface, network parameters are divided into separate menus which are accessed via the Network Configuration flyout menu.

Notes:

- *Settings for network parameters depend on the configuration of your network. Please contact your network administrator for appropriate settings.*
- *The Network Parameters Menu selects parameters for all logical Network Ports.*
- *The IP Address, Subnet Address and Gateway Address cannot be changed via the Web Browser Interface. In order to change these parameters, you must access the unit via the Text Interface.*
- *When a new IP Address is selected, or the status of the DHCP feature is changed, the unit will disconnect and reconfigure itself with the new values when you exit the Network Parameters Menu. When configuring the unit via Web or Telnet, make certain your DHCP server is set up to assign a known, fixed IP address in order to simplify reconnection to the unit after the new address has been assigned.*
- *The Network Parameters menu is only available when you have logged into command mode using an account and port that permit Administrator level commands (Administrator Mode enabled.)*

Both IPv4 and IPv6 parameters can be defined for the Ethernet port, and the unit will automatically use the appropriate protocol to match incoming Ethernet connections. Note that both the IPv4 configuration menu and the IPv6 configuration menu offer essentially the same parameters.

- **Text Interface:**

To define network parameters for the IPv4 protocol, type `/N` and press **[Enter]**.

To define network parameters for the IPv6 protocol, type `/N6` and press **[Enter]**.

- **Web Browser Interface:** Place the cursor over the "Network Configuration" link on the left hand side of the screen, wait for the fly-out menu to appear, and then click on the link to display the desired menu. Note that some submenus offer the option to define IPv4 or IPv6 parameters and that IPv4 and IPv6 menus include a link that can be used to jump to the other protocol.

6.6.1. Network Port Parameters

In the Text Interface, these parameters are found in the main Network Configuration menu. In the Web Browser Interface, these parameters are found by placing the cursor over the "Network Configuration" link on the left hand side of the screen, and then clicking on the "Network Port Parameters" link in the resulting fly-out menu.

Note: *The settings for the following parameters defined via the Network Port Parameters menu (Web Interface) and Network Parameters menu (Text Interface) will also be applied to the USB Mini format SetUp Port: Administrator Mode, Logoff Character, Sequence Disconnect, Inactivity Timeout, Command Echo and Accept Break.*

- **Administrator Mode:** Permits/denies port access to accounts that allow Administrator level commands. When enabled (Permit), the port will be allowed to invoke Administrator level commands, providing they are issued by an account that permits them. If disabled (Deny), then accounts that permit Administrator level commands will not be allowed to access command mode via this port. (Default = Permit)

Notes:

- *If Administrator Mode is disabled at the Network Port, then you will not be able to access configuration, command and status display functions via network.*
- *The setting for the Administrator Mode parameter will also be applied to the USB Mini format SetUp Port.*
- **Logoff Character:** Defines the Logoff Character for the network port. This determines which command(s) must be issued at this port in order to disconnect from a second port. (Default = ^x ([Ctrl] plus [X]))

Notes:

- *The Sequence Disconnect parameter can be used to pick a one character or a three character logoff sequence.*
- *The setting for the Logoff Character parameter will also be applied to the USB Mini format SetUp Port.*
- **Sequence Disconnect:** Enables/Disables and configures the Resident Disconnect command. Offers the option to either disable the Sequence Disconnect, or select a one character, or three character command format. (Default = One Character).

Notes:

- *The One Character Disconnect is intended for situations where the destination port should **not** receive the disconnect command. When the Three Character format is selected, the disconnect sequence **will** pass through to the destination port prior to breaking the connection.*
- *When Three Character format is selected, the Resident Disconnect uses the format "[Enter]LLL[Enter]", where L is the selected Logoff Character.*
- *The setting for the Sequence Disconnect parameter will also be applied to the USB Mini format SetUp Port.*

- **Inactivity Timeout:** Enables and selects the Inactivity Timeout period for the Network Port. If enabled, and the port does not receive or transmit data for the specified time period, the port will disconnect. (Default = 5 Minutes)

Note: *The setting for the Inactivity Timeout parameter will also be applied to the USB Mini format SetUp Port.*

- **Command Echo:** Enables or Disables the command echo for the Network Port. (Default = On).

Note: *The setting for the Command Echo parameter will also be applied to the USB Mini format SetUp Port.*

- **Accept Break:** Determines whether the port will accept breaks received from the attached device, and pass them along to a connected port. When enabled, breaks received at this port will be passed to any port this port is connected to, and sent to the device connected to the other port. When disabled, breaks will be refused at this port. (Default = On)

Note: *The setting for the Accept Break parameter will also be applied to the USB Mini format SetUp Port.*

- **Multiple Logins:** (Text Interface Only) If the SRM is installed in an environment that *does not* include communication via an open network (local communication only), then the Multiple Logins parameter can be used to determine whether or not multiple users will be able to communicate with the unit at the same time. If this parameter is set to "Off" then only one user will be allowed to communicate with the unit at a time. (Default = On)

6.6.2. Network Parameters

In the Text Interface, these parameters are accessed via the main Network Configuration menu, which is activated by typing `/N` (for IPv4 parameters) or `/N6` (for IPv6 parameters) and then pressing **[Enter]**. In the Web Browser Interface, these parameters are found by placing the cursor over the "Network Configuration" link on the left hand side of the screen, and then clicking on the "Network Parameters" link in the resulting fly-out menu.

Note: *The IP Address, Subnet Mask, Gateway Address and DHCP status cannot be changed via the Web Browser Interface. In order to change these parameters, you must access the SRM via the Text Interface.*

- **IP Address:** (Defaults: IPv4 = 192.168.168.168; IPv6= undefined)
- **Subnet Mask:** (IPv4 Only; Default = 255.255.255.0)
- **Subnet Prefix:** (IPv6 Only; Default = undefined)
- **Gateway Address:** (Default = undefined)
- **DHCP:** Enables/Disables Dynamic Host Configuration Protocol. When enabled, the SRM will perform a DHCP request. Note that in the Text Interface, the MAC address for the SRM is listed on the Network Status Screen. (Default = On)

Note: *Before configuring this feature via Telnet or Web, make certain your DHCP server is set up to assign a known, fixed IP address. You will need this new IP address in order to reestablish a network connection with the SRM.*

- **IP Security:** Provides access to a submenu that is used to enable and define the IP Security filter as described in Section 6.6.3. (Default = Off)

Note: *In the Web Interface, IP Security parameters are defined via a separate submenu which is accessed via a flyout menu under the Network Parameters Link on the left hand side of the screen.*

- **Static Route:** Provides access to a submenu that is used to enable and define Static Route functions as described in Section 6.6.4. (Default = Off)

Note: *In the Web Interface, Static Route parameters are defined via a separate submenu which is accessed via a flyout menu under the Network Parameters Link on the left hand side of the screen.*

- **DNS Servers:** Provides access to a submenu that is used to define Domain Name Server parameters as described in Section 6.6.5. (Default = undefined)

Note: *In the Web Interface, DNS Server parameters are defined via a separate submenu which is accessed via a flyout menu under the Network Parameters Link on the left hand side of the screen.*

- **Negotiation:** (Text Interface Only) This parameter can be used to solve synchronization problems when the SRM unit negotiates communication parameters with another device. (Default = Auto)

Notes:

- *If the other device is set for automatic negotiation, then the SRM's Negotiation parameter should also be set to Auto.*
- *If the other device is not set for automatic negotiation, then the SRM's Negotiation parameter should be set to match the other device (e.g., "100/Full.)*

- **Telnet Access:** Enables/disables Telnet access. When Telnet Access is "Off," users will not be allowed to establish a Telnet connection to the unit or initiate outbound Telnet or SSH connections. (Default = On)
- **Telnet Port:** Selects the TCP/IP port number that will be used for Telnet connections. (Default = 23)

Note: *In the Text Interface, this item is defined via a submenu, which is displayed when the Telnet Access parameter is selected.*

- **Max. Per Source (Per Source):** The maximum number of Telnet sessions that will be allowed per user MAC address. (Default = 4)

Notes:

- *In the Text Interface, the "Max. Per Source" (Per Source) parameter is defined via a submenu of item 21 (Telnet Access) in the Network Parameters menu.*
 - *After changing the "Max Per Source" parameter, you must log out of all pre-existing Telnet sessions in order for the new maximum value to be applied.*
 - **SSH Access:** Enables/disables SSH communication. (Default = On)
 - **SSH Port:** The TCP/IP port number used for SSH connections. (Default = 22)
- Note:** *In the Text Interface, this item is defined via a submenu, which is displayed when SSH Access is selected.*
- **SSH View Port Enable:** (Text Interface Only) Allows monitoring of Serial Port activity. (Default = Off)
- Note:** *This item is defined via a submenu, which is displayed when SSH Access is selected.*
- **SSH View Port Bidirection:** (Text Interface Only) Allows monitoring of bidirectional Serial Port Activity. (Default = Off)
- Note:** *This item is defined via a submenu, which is displayed when SSH Access is selected.*
- **HTTP Access (Web Access):** Enables/disables the Web Browser Interface. When disabled, users will not be allowed to contact the unit via the Web Browser Interface. (Default = Off)
 - **HTTP Port:** The TCP/IP port number used for HTTP connections. (Default = 80)
 - **HTTPS Access:** Enables/disables HTTPS communication. For instructions on setting up SSL encryption, please refer to Section 12. (Default = Off)

- **HTTPS Port:** Selects the TCP/IP port number that will be used for HTTPS connections. (Default = 443)

Notes:

- *In the Text Interface, HTTP and HTTPS parameters reside in a separate submenu. To enable and configure HTTP and HTTPS Access via the Text Interface, access the Network Configuration Menu as described in Section 6.6, then type 23, press **[Enter]** and use the resulting submenu (Figure 12.1) to select parameters as described in Section 12.*
- *When the Web Access parameter is accessed via the Text Interface, the resulting submenu will also allow you to select SSL (encryption) parameters as described in Section 12.*
- **Harden Web Security:** When the Harden Web Security feature is On (default,) only the high and medium cypher suites for SSLv3 and TLSv1 will be enabled. When the Harden Web Security feature is Off, all SSL protocols will be enabled, allowing compatibility with older browsers. (Default = Medium)

Note: *In the Text Interface, this option is enabled/disabled via the Web Access submenu.*

- **TLS Mode:** Selects TLSv1 or TLSv1.1. Although TLSv1.1 provides better security, the default settings of most browsers do not support TLSv1.1. For more information, please refer to Section 12.4. (Default = TLSv1.1/TLSv1.2)

Note: *In the Text Interface, the TLS Mode parameter is located in the Web Access submenu.*

- **SYSLOG Addresses:** Defines the IP addresses for the Syslog Daemon(s) that will receive log records generated by the SRM. Allows definition of IP addresses for both a primary Syslog Daemon and an optional secondary Syslog Daemon. SYSLOG Addresses can be entered in either IPv4 or IPv6 format, or in domain name format (up to 64 characters.) For more information, please refer to Section 10. (Default = undefined)

Notes:

- *The Syslog Address submenu in the Text Interface and the Network Parameters submenu in the Web Browser Interface both include a Ping Test function that can be used to ping the user-selected Syslog IP Addresses in order to verify that valid IP addresses have been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined Syslog Addresses in order to make certain that the IP addresses are responding.*
- **SNMP Access:** Displays a submenu which is used to define SNMP Access parameters as described in Section 6.6.6.

Note: *To define SNMP Access parameters via the Web Browser place the cursor over the Network Configuration link on the left hand side of the screen. When the flyout menu appears, select SNMP Parameters.*

- **SNMP Trap Parameters:** Displays a submenu which is used to define SNMP Trap parameters as described in Section 6.6.7.
Note: *To define SNMP Trap parameters via the Web Browser place the cursor over the Network Configuration link on the left hand side of the screen. When the flyout menu appears, select SNMP Traps.*
- **LDAP:** Displays a submenu which is used to define LDAP parameters as described in Section 6.6.8.
Note: *To define LDAP parameters via the Web Browser place the cursor over the Network Configuration link on the left hand side of the screen. When the flyout menu appears, select LDAP Parameters.*
- **TACACS:** Displays a submenu which is used to define TACACS parameters as described in Section 6.6.9.
Note: *To define TACACS parameters via the Web Browser place the cursor over the Network Configuration link on the left hand side of the screen. When the flyout menu appears, select TACACS.*
- **RADIUS:** Displays a submenu which is used to define RADIUS parameters as described in Section 6.6.10.
Note: *To define RADIUS parameters via the Web Browser place the cursor over the Network Configuration link on the left hand side of the screen. When the flyout menu appears, select RADIUS.*
- **Email Messaging:** Displays a submenu which is used to define Email Messaging parameters as described in Section 6.6.11
Note: *To define Email Messaging parameters via the Web Browser place the cursor over the Network Configuration link on the left hand side of the screen. When the flyout menu appears, select Email Messaging.*
- **Ping Access:** Configures the SRM's response to ping commands. Ping Access can be set to block all ping commands, allow all ping commands or only accept ping commands from user specified IP addresses (Limited.) When the "Limited" option is selected, up to four permitted IP address can be defined via the submenu. Note that disabling Ping Access at the Network Port will not effect the operation of the Ping-No-Access Alarm. (Default = Allow All)
- **Outbound Access:** Enables/Disables the ability to create outbound Telnet and/or SSH connections via the SRM's Network Port. When enabled, users who are connected to the SRM command mode via one of the serial ports will be able to connect to the Network Port, and then invoke the /TELNET and/or /SSH commands to create an outbound connection. For example, to create an outbound Telnet connection, first make certain that this option is enabled for both the serial port and the password/account, then access command mode via the Text Interface at a free serial port. At the command prompt, invoke the /TELNET command as described in Section 9.4. (Default = Off)

- **Outbound Secure Level:** When Outbound Access is enabled, this parameter is used to determine whether outbound connections will be allowed to be established via both the Serial Port and Network Port, or via the Serial Port only. (Default = Serial Only.)

Note: *In the Text Interface, the Outbound Secure Level prompt can be found in the Outbound Access submenu.*

- **Raw Socket Access:** Function not available on SRM units.
- **Modem Hunt Telnet:** Function not available on SRM units.
- **Modem Hunt Raw:** Function not available on SRM units.
- **Ping Syslog Servers:** (Ping Test) Pings the IP addresses which have been defined for the SYSLOG Servers in order to check for a response.

Notes:

- *The Syslog Address submenu in the Text Interface and the Network Parameters submenu in the Web Browser Interface both include a Ping Test function that can be used to ping the user-selected Syslog IP Addresses in order to verify that valid IP addresses have been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined Syslog Addresses in order to make certain that the IP addresses are responding.*

6.6.3. IP Security

The IP Security feature allows the SRM to restrict unauthorized IPv4 or IPv6 format IP addresses from establishing inbound Telnet connections to the unit. This allows you to grant Telnet access to only a specific group of IP addresses, or block a particular IP address completely. In the default state, the SRM accepts incoming IP connections from all hosts.

In the Text Interface, IP Security parameters are defined via item 5 in the Network Configuration menu. In the Web Browser Interface, these parameters are found by placing the cursor over the "Network Configuration" link on the left hand side of the screen, and then clicking on the "IP Security" link in the resulting fly-out menu.

The IP Security Function employs a TCP Wrapper program which allows the use of standard, Linux operators, wild cards and net/mask pairs to create a host based access control list.

The IP Security configuration menus include "hosts.allow" and "hosts.deny" client lists. Basically, when setting up IP Security, you must enter IP addresses for hosts that you wish to allow in the Allow list, and addresses for hosts that you wish to deny in the Deny list. Since Linux operators, wild cards and net/mask pairs are allowed, these lists can indicate specific addresses, or a range of addresses to be allowed or denied.

When the IP Security feature is properly enabled, and a client attempts to connect, the SRM will perform the following checks:

1. If the client's IP address is found in the "hosts.allow" list, the client will be granted immediate access. Once an IP address is found in the Allow list, the SRM will not check the Deny list, and will assume you wish to allow that address to connect.
2. If the client's IP address is not found in the Allow list, the SRM will then proceed to check the Deny list.
3. If the client's IP Address *is* found in the Deny list, the client *will not* be allowed to connect.
4. If the client's IP Address *is not* found in the Deny list, the client *will* be allowed to connect, even if the address was not found in the Allow list.

Notes:

- *If the SRM finds an IP Address in the Allow list, it will not check the Deny list, and will allow the client to connect.*
- *If both the Allow and Deny lists are left blank, then the IP Security feature will be disabled, and all IP Addresses will be allowed to connect (providing that the proper password and/or SSH key is supplied.)*
- *When the Allow and Deny lists are defined, the user is only allowed to specify the Client List; the Daemon List and Shell Command cannot be defined.*

6.6.3.1. Adding IP Addresses to the Allow and Deny Lists

To add an IPv4 or IPv6 format IP Address to the Allow or Deny list, and begin configuring the IP Security feature, proceed as follows.

Notes:

- *Both the Allow and Deny list can include Linux operators, wild cards, and net/mask pairs.*
- *In some cases, it is not necessary to enter all four "digits" of the IP Address. For example, if you wish to allow access to all IP addresses that begin with "192," then you would only need to enter "192."*
- *The IP Security Configuration menu is only available when the Administrator Mode is active.*
- *In order to use domain names in the Allow List and/or Deny List, you must first define IP address(es) for the desired Domain Name Server(s) as described in Section 6.6.5.*

1. Access the IP Security Configuration Menu.
 - a) **Text Interface:** Type `/N` **[Enter]** to define addresses in IPv4 format, or type `/N6` and press **[Enter]** to define addresses in IPv6 format. The Network Configuration Menu will be displayed. From the Network Configuration Menu, type 5 **[Enter]** to display the IP Security Menu.
 - b) **Web Browser Interface:** Place the cursor over the "Network Configuration" link on the left hand side of the screen. When the fly-out menu appears, click on the "IP Security" Link to display the IP Security Menu. The IP Security menu in the Web Browser Interface will accept addresses in either IPv4 or IPv6 format.
2. **Allow List:** Enter the IP Address(es) for the clients that you wish to allow. Note that if an IP Address is found in the Allow list, the client will be allowed to connect, and the SRM will not check the Deny list.
 - a) **Text Interface:** Note the number for the first empty field in the Allow list, then type that number at the command prompt, press **[Enter]**, and then follow the instructions in the resulting submenu.
 - b) **Web Browser Interface:** Place the cursor in the first empty field in the parameters menu, then key in the desired IP Address, operators, wild cards, and/or net/mask pairs.
3. **Deny List:** Enter the IP Address(es) for the clients that you wish to deny. Note that if the client's IP Address is not found in the Deny List, that client will be allowed to connect. Use the same procedure for entering IP Addresses described in Step 2 above.

6.6.3.2. Linux Operators and Wild Cards

In addition to merely entering a specific IP address or partial IP address in the Allow or Deny list, you may also use any standard Linux operator or wild card. In most cases, the only operator used is "EXCEPT" and the only wild card used is "ALL," but more experienced Linux users may note that other operators and wild cards may also be used.

EXCEPT:

This operator creates an exception in either the "allow" list or "deny" list.

For example, if the Allow list includes a line which reads "192. EXCEPT 192.255.255.6," then all IP address that begin with "192." will be allowed; except 192.255.255.6 (providing that this address appears in the Deny list.)

ALL:

The ALL wild card indicates that all IP Addresses should be allowed or denied. When ALL is included in the Allow list, all IP addresses will be allowed to connect; conversely, if ALL is included in the Deny list, all IP Addresses will be denied (except for IP addresses listed in the Allow list.)

For example, if the Deny list includes a line which reads "ALL EXCEPT 168.255.192.192," then all IP addresses except 168.255.192.192 will be denied (except for IP addresses that are listed in the Allow list.)

Net/Mask Pairs:

An expression of the form "n.n.n.n/m.m.m.m" is interpreted as a "net/mask" pair. A host address is matched if "net" is equal to the bitwise AND of the address and the "mask."

For example, the net/mask pattern "131.155.72.0/255.255.254.0" matches every address in the range "131.155.72.0" through "131.155.73.255."

6.6.3.3. IP Security Examples

1. **Mostly Closed:** Access is denied by default and the only clients allowed, are those explicitly listed in the Allow list. To deny access to all clients except 192.255.255.192 and 168.112.112.05, the Allow and Deny lists would be defined as follows:

- Allow List:
 1. 192.255.255.192
 2. 168.112.112.05
- Deny List:
 1. ALL

2. **Mostly Open:** Access is granted by default, and the only clients denied access, are those explicitly listed in the Deny list, and as exceptions in the Allow list. To allow access to all clients except 192.255.255.192 and 168.112.112.05, the Allow and Deny lists would be defined as follows:

- Allow List:
 1. ALL EXCEPT 192.255.255.192, 168.112.112.05
- Deny List:
 1. 192.255.255.192, 168.112.112.05

Notes:

- *When defining a line in the Allow or Deny list that includes several IP addresses, each individual address is separated by either a space, a comma, or a comma and a space as shown in Example 2 above.*
- *Take care when using the "ALL" wild card. When ALL is included in the Allow list, it should always include an EXCEPT operator in order to allow the unit to proceed to the Deny list and determine any addresses you wish to deny.*

6.6.4. Static Route

The Static Route menu allows you to type in Linux routing commands that will be automatically executed each time that the unit powers up or reboots. In the Text Interface, the Static Route menu is accessed via the Network Configuration menu. In the Web Browser Interface, the Static Route menu is accessed via the flyout menus under the Network Configuration link. Note that parameters defined via this menu will be applied to both IPv4 and IPv6 communication.

6.6.5. Domain Name Server

The DNS menu is used to select IPv4 or IPv6 format IP addresses for Domain Name Servers. When web and network addresses are entered, the Domain Name Server interprets domain names (e.g., www.wti.com), and translates them into IP addresses. In the Text Interface, the DNS menu is accessed via the Network Configuration menu. In the Web Browser Interface, the DNS menu is accessed via the flyout menus under the Network Configuration link. Note that if you don't define at least one DNS server, then IP addresses must be used, rather than domain names. Note that parameters defined via this menu will be applied to both IPv4 and IPv6 communication.

The Domain Name Server menu includes a Ping Test feature, that allows you to ping the IP addresses for each user-defined domain name server in order to check that a valid IP address has been entered.

Note: *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*

6.6.6. SNMP Access Parameters

These menus are used to select access parameters for the SNMP feature. In the Text Interface, the SNMP Access Parameters menu is accessed via the Network Configuration menu. In the Web Browser Interface, the SNMP Access Parameters menu is accessed via the flyout menus under the Network Configuration link.

Notes:

- *After you have configured SNMP Access Parameters, you will then be able to manage the SRM's User Directory and display unit status via SNMP, as described in Section 11.*
- *In the Text Interface, SNMP Access Parameters are defined via two separate menus that are accessed via either the `/n` command (IPv4) or the `/n6` command (IPv6.)*
- *In the Web Browser interface, both IPv4 and IPv6 SNMP Access Parameters are defined via a single menu. When defining IPv6 parameters, make certain that the IPv6 checkbox in the SNMP Access Parameters menu is checked.*

The SNMP Access Parameters menu allows the following parameters to be defined:

- **Enable:** Enables/disables SNMP Polling. (Default = Off)

Note: *This item only applies to external SNMP polling of the SRM; it does not effect the ability of the SRM to send SNMP traps.*

- **Version:** This parameter determines which SNMP Version the SRM will respond to. For example, if this item is set to V3, then clients who attempt to contact the SRM using SNMPv2 will not be allowed to connect. (Default = V1/V2 Only)

- **Read Only:** Enables/Disables the "Read Only Mode", which controls the ability to access configuration functions and invoke switching commands. When Enabled, you will not be able to change configuration parameters or invoke other commands when you contact the SRM via SNMP. (Default = No)

Note: *In order to define user names for the SRM via your SNMP client, the Read Only feature must be disabled. When the Read Only feature is enabled, you will not be able to issue configuration commands to the unit via SNMP.*

- **Authentication / Privacy:** Configures the Authentication and Privacy features for SNMPv3 communication. The Authentication / Privacy parameter offers two options, which function as follows:
 1. **Auth/noPriv:** An SNMPv3 username and password will be required at log in, but encryption will not be used. (Default Setting)
 2. **Auth/Priv:** An SNMPv3 username and password will be required at log in, and all messages will be sent using encryption.

Notes:

- *The Authentication / Privacy item is not available when the Version parameter is set to V1/V2.*
- *If the Version Parameter is set to V1/V2/V3 (all) and Authentication / Privacy parameter is set to "Auth/Priv", then only V3 data will be encrypted.*
- *The SRM does not support "noAuth/noPriv" for SNMPv3 communication.*
- **SNMPv3 User Name:** Sets the User Name for SNMPv3. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined)
- **SNMPv3 Password:** Sets the password for SNMPv3. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined)
- **SNMPv3 Password Confirm:** This prompt is used to confirm the SNMPv3 password that was entered at the prompt above. Note that this option is not available when the Version parameter is set to V1/V2. (Default = undefined)
- **Authentication Protocol:** This parameter determines which authentication protocol will be used. The SRM supports both MD5 and SHA1 authentication. (Default = MD5)

Notes:

- *The Authentication Protocol that is selected for the SRM must match the protocol that your SNMP client will use when querying the SRM unit.*
- *The Authentication Protocol option is not available when the Version parameter is set to V1/V2*
- **Privacy Protocol:** (SNMPv3 Only) Selects AES or DES encryption support. (Default = DES)

Note: *SNMPv2 does not support encryption.*

- **SNMP Contact:** (Default = undefined)
- **SNMP Location:** (Default = undefined)
- **Read Only Community:** Note that this parameter is not available when the SNMP Version is set to V3. (Default = Public)
- **Read/Write Community:** Note that this parameter is not available when the SNMP Version is set to V3. (Default = Public)

6.6.7. SNMP Trap Parameters

These menus are used to select parameters that will be used when SNMP traps are sent. For more information on SNMP Traps, please refer to Section 11. In the Text Interface, the SNMP Trap Parameters menu is accessed via the Network Configuration menu. In the Web Browser Interface, the SNMP Trap Parameters menu is accessed via the flyout menus under the Network Configuration link. The SNMP Trap Parameters menu allows the following parameters to be defined:

Notes:

- *In the Text Interface, SNMP Trap parameters are defined via two separate menus that are accessed via either the `/N` command (IPv4) or the `/N6` command (IPv6.)*
- *In the web browser interface, SNMP Trap parameters are defined via two separate submenus that are accessed via the IPv4 or IPv6 flyout menus, under the SNMP Traps link.*
- **SNMP Manager 1:** The IP Address for the first SNMP Manager. For more information, please refer to Section 11. (Default = Undefined)
Note: *In order to enable the SNMP Trap feature, you must define at least one SNMP Manager.*
- **SNMP Manager 2:** (Default = undefined)
- **Trap Community:** (Default = Public)
- **Trap Version:** The assigned security level for SNMP traps. (Default = V1)
- **V3 Trap Engine ID:** The V3 SNMP agent's unique identifier. (Default = undefined)
- **Ping Test:** Allows you to ping the IP addresses or domain names defined via the SNMP Manager 1 and SNMP Manager 2 prompts in order to check that a valid IP address or domain name has been entered.

Notes:

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the `/TEST` command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping the currently defined SNMP Managers in order to make certain that the IP addresses are responding.*

6.6.8. LDAP Parameters

The SRM supports LDAP (Lightweight Directory Access Protocol,) which allows authentication via the "Active Directory" network Directory Service. When LDAP is enabled, command access rights can be granted to new users without the need to define individual new accounts at each SRM unit, and existing users can also be removed without the need to delete the account from each SRM unit. This also allows administrators to assign users to LDAP groups, and then specify access rights for members of each group.

In order to apply the LDAP feature, you must first define User Names and associated Passwords and group membership via your LDAP server, and then access the SRM command mode to configure LDAP settings and define port access rights and command access rights for each group specified at the LDAP server. To access the LDAP Parameters menu, login to SRM command mode using a password that permits Administrator level commands.

Notes:

- *In the Text Interface, the LDAP Parameters menu is accessed via the Network Configuration menu (/N for IPv4 parameters or /N6 for IPv6 parameters.)*
- *In the Web Browser Interface, both IPv4 and IPv6 parameters are defined via a single LDAP Parameters menu, which is accessed via the flyout menus under the Network Configuration link.*
- *Port access rights are not defined at the LDAP server. They are defined via the LDAP Group configuration menu on each SRM unit and are specific to that SRM unit alone.*
- *When LDAP is enabled, LDAP authentication will supersede any passwords and access rights that have been defined via the SRM user directory.*
- *If no LDAP groups are defined on a given SRM unit, then access rights will be determined as specified by the "default" LDAP group.*
- *The "default" LDAP group cannot be deleted.*

The LDAP Parameters Menu allows the following parameters to be defined:

- **Enable:** Enables/disables LDAP authentication. (Default = Off)
- **Primary Host IPv4:** Defines the IP address or domain name for the primary LDAP server when IPv4 protocol is used to communicate with the SRM unit. (Default = undefined)
- **Primary Host IPv6:** Defines the IP address or domain name for the primary LDAP server when IPv6 protocol is used to communicate with the SRM unit. (Default = undefined)
- **Secondary Host IPv4:** Defines the IP address or domain name for the secondary (fallback) LDAP server when IPv4 protocol is used. (Default = undefined)
- **Secondary Host IPv6:** Defines the IP address or domain name for the secondary (fallback) LDAP server when IPv6 protocol is used. (Default = undefined)

- **LDAP Port:** Defines the port that will be used to communicate with the LDAP server. (Default = 389)
- **TLS/SSL:** Enables/Disables TLS/SSL encryption. Note that when TLS/SSL encryption is enabled, the LDAP Port should be set to 636. (Default = Off)
- **Bind Type:** Sets the LDAP bind request password type. Note that in the Text Interface, when the Bind Type is set to "Kerberos" LDAP, the menu will include additional prompts used to select Kerberos parameters. (Default = Simple)
- **Search Bind DN:** Selects the user name who is allowed to search the LDAP directory. (Default = undefined)
- **Search Bind Password:** Sets the Password for the user who is allowed to search the LDAP directory. (Default = undefined)
- **User Search Base DN:** Sets the directory location for user searches. (Default = undefined)
- **User Search Filter:** Selects the attribute that lists the user name. Note that this attribute should always end with "=%s" (no quotes.) (Default = undefined)
- **Group Membership Attribute:** Selects the attribute that list group membership(s). (Default = undefined)
- **Group Membership Value Type:** (Default = DN)
- **Fallback:** Enables/Disables the LDAP fallback feature. When enabled, the SRM will revert to it's own internal user directory if no defined users are found via the LDAP server. In this case, port access rights will then be granted as specified in the default LDAP group. (Default = Off)
- **Kerberos Setup:** Kerberos is a network authentication protocol, which provides a secure means of identity verification for users who are communicating via a non-secure network. In the Text Interface, Kerberos parameters are selected via a submenu that is only available when Kerberos is selected as Bind Type. In the Web Browser Interface, Kerberos parameters are defined via the main LDAP Parameters menu. The following parameters are available:
 - ◆ **Port:** (Default = 88)
 - ◆ **Realm:** (Default = Undefined)
 - ◆ **Key Distribution Centers (KDC1 through KDC5):** (Default = Undefined)
 - ◆ **Domain Realms 1 through 5:** (Default = Undefined)
- **LDAP Group Setup:** Provides access to a submenu, which is used to define LDAP Groups as described in the Sections 6.6.8.1 through 6.6.8.4.

- **Debug:** This option is used to assist WTI Technical Support personnel with the diagnosis of LDAP issues. (Default = Off)
- **Ping Test:** Allows you to ping IP addresses or domain names that have been defined via the LDAP Parameters menus in order to check that a valid IP address or domain name has been entered.

Notes:

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

6.6.8.1. Adding LDAP Groups

Once you have defined several users and passwords via your LDAP server, and assigned those users to LDAP Groups, you must then grant command and port access rights to each LDAP Group at each individual SRM unit.

To add LDAP groups to your SRM unit, log in to the command mode using a password that permits access to Administrator level commands. The Add LDAP Group menu allows the following parameters to be defined:

- **Group Name:** Note that this name must match the LDAP Group names that you have assigned to users at your LDAP server. (Default = undefined)
- **Access Level:** Sets the command access level to either Administrator, SuperUser, User or ViewOnly. For more information, please refer to Section 6.3.1. (Default = User)
- **Port Access:** This item is used to select the serial ports that members of this LDAP group will be allowed to connect. (Default = undefined)

Note: *The Port Access parameter can also be used to grant or deny user access to the internal modem port.*

- **Service Access:** Selects access methods for this LDAP Group. Determines whether members of this LDAP Group will be allowed to access command mode via Serial Port, Telnet/SSH, Web and/or to establish outbound connections. Also enables/disables Outbound Telnet. (Default; Serial Port = On, Telnet/SSH = On, Outbound Access = Off.)

Note: *After defining LDAP Group parameters, make certain to save changes before proceeding. In the Web Browser Interface, click on the "Add LDAP Group" button to save parameters; in the Text Interface, press the [Esc] key several times until the SRM displays the "Saving Configuration" message.*

6.6.8.2 Viewing LDAP Groups

If you want to examine an existing LDAP group definition, the "View LDAP Groups" function can be used to review the group's parameters.

6.6.8.3. Modifying LDAP Groups

If you want to modify an existing LDAP Group in order to change parameters, the "Modify LDAP Group" function can be used to reconfigure group parameters. To Modify an existing LDAP Group, access the SRM command mode using a password that permits access to Administrator Level commands. Once you have accessed the Modify LDAP Group menu, use the menu options to redefine parameters in the same manner that is used for the Add LDAP Group menu, as discussed in Section 6.6.8.1.

Note: *After you have finished modifying LDAP Group parameters, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Modify LDAP Group" button to save parameters; in the Text Interface, press the [Esc] key several times until the SRM displays the "Saving Configuration" message and the cursor returns to the command prompt.*

6.6.8.4. Deleting LDAP Groups

The Delete LDAP Group function is used to delete LDAP Groups that are no longer in use. In order to delete LDAP Groups, you must access the SRM command mode using a password that permits access to Administrator Level commands.

6.6.9. TACACS Parameters

The TACACS Configuration Menus offer the following options:

- **Enable:** Enables/disables the TACACS feature at the Network Port. (Default = Off)
- **Primary Address:** The IP address or domain name for your primary TACACS server. (Default = undefined)
- **Secondary Address:** The IP address or domain name for your secondary, fallback TACACS server. (Default = undefined)
- **Secret Word:** The shared TACACS Secret Word for both TACACS servers. (Default = undefined)
- **Fallback Timer:** Determines how long the unit will attempt to contact the primary TACACS Server before falling back to the secondary server. (Default = 15 Seconds)
- **Fallback Local:** Determines whether or not the SRM will fallback to its own username directory when an authentication attempt fails. When enabled, the unit will first attempt to authenticate the password by checking the TACACS Server. If this fails, the unit will then attempt to authenticate the password by checking its own internal username directory. This parameter offers three options:
 - ◆ **Off:** Fallback Local is disabled (Default)
 - ◆ **On (All Failures):** Fallback Local is enabled, and the unit will fallback to its own internal user directory when it cannot contact the TACACS Server, or when a password or username does not match the TACACS Server.
 - ◆ **On (Transport Failure):** Fallback Local is enabled, but the unit will only fallback to its own internal user directory when it cannot contact the TACACS Server.
- **Authentication Port:** The port number for the TACACS function. (Default = 49)
- **Default User Access:** When enabled, allows TACACS users to access the unit without first defining a TACACS user account on the SRM. When new TACACS users access the unit, they will inherit the default Access Level, Port Access and Service Access defined via the items listed below: (Default = On)
 - **Enable:** Enables/disables the Default User Access function. (Default = On)
 - **Access Level:** Determines the default Access Level setting for new TACACS users. This option can set the default access level for new TACACS users to "Administrator", "SuperUser", "User" or "ViewOnly." For more information, please refer to Section 6.3.1 and Section 15.2. (Default = User)

- **Port Access:** Determines the default Port Access setting for new TACACS users. The Port Access setting determines which serial ports each account will be allowed to control. (Defaults; Administrator and SuperUser = All Ports On, User = undefined, ViewOnly = undefined)

Notes:

- *Administrator and SuperUser level accounts always have access to all ports.*
- *User level accounts will only have access to ports specified via the "Port Access" parameter.*
- *ViewOnly level can view the connection status of permitted serial ports, but are not allowed to create connections between ports.*

- **Service Access:** Selects the default Service Access setting for new TACACS users. Determines whether each account will be able to access command mode via Serial Port, Telnet/SSH or Web. In addition, the Service Access setting also determines whether each account will be able to employ the Outbound Access function. (Default = Serial Port = On, Telnet/SSH = On, Web = On, Outbound Access = Off.)

Note: *If Outbound Access has been disabled via the Network Parameters menu, then the Service Access parameter will not be allowed to grant Outbound Access to new TACACS users.*

- **Ping Test (Ping TACACS Servers):** Allows you to ping IP addresses or domain names that have been defined via the TACACS Parameters menus in order to check that a valid IP address or domain name has been entered.

Notes:

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

6.6.10. RADIUS Parameters

In the Text Interface, the RADIUS Parameters menu is accessed via the Network Configuration menu (/N for IPv4 parameters or /N6 for IPv6 parameters.) In the Web Browser Interface, both IPv4 and IPv6 parameters are defined via a single RADIUS Parameters menu, which is accessed via the flyout menus under the Network Configuration link. The RADIUS Configuration Menus offer the following options:

- **Enable:** Enables/disables the RADIUS feature at the Network Port. (Default = Off)
- **Primary Address IPv4:** Defines the IP address or domain name for your primary RADIUS server when IPv4 protocol is used. (Default = undefined)
- **Primary Address IPv6:** Defines the IP address or domain name for your primary RADIUS server when IPv6 protocol is used. (Default = undefined)
- **Primary Secret Word:** Defines the RADIUS Secret Word for the primary RADIUS server. (Default = undefined)
- **Secondary Address IPv4:** Defines the IP address or domain name for your secondary, fallback RADIUS server when IPv4 protocol is used. (Default = undefined)
- **Secondary Address IPv6:** Defines the IP address or domain name for your secondary, fallback RADIUS server when IPv6 protocol is used. (Default = undefined)
- **Secondary Secret Word:** Defines the RADIUS Secret Word for the secondary RADIUS server. (Default = undefined)
- **Fallback Timer:** Determines how long the SRM will continue to attempt to contact the primary RADIUS Server before falling back to the secondary RADIUS Server. (Default = 3 Seconds)
- **Fallback Local:** Determines whether or not the SRM will fallback to its own password/username directory when an authentication attempt fails. When enabled, the SRM will first attempt to authenticate the password by checking the RADIUS Server; if this fails, the SRM will then attempt to authenticate the password by checking its own internal username directory. This parameter offers three options:
 - ◆ **Off:** Fallback Local is disabled (Default.)
 - ◆ **On (All Failures):** Fallback Local is enabled, and the unit will fallback to its own internal user directory when it cannot contact the Radius Server, or when a password or username does not match the Radius Server.
 - ◆ **On (Transport Failure):** Fallback Local is enabled, but the unit will only fallback to its own internal user directory when it cannot contact the Radius Server.
- **Retries:** Determines how many times the SRM will attempt to contact the RADIUS server. Note that the retries parameter applies to both the Primary RADIUS Server and the Secondary RADIUS Server. (Default = 3)
- **Authentication Port:** The Authentication Port number for the RADIUS function. (Default = 1812)

- **Accounting Port:** The Accounting Port number for the RADIUS function. (Default = 1813)
- **Debug:** (Text Interface Only) When enabled, the SRM will put RADIUS debug information into Syslog. (Default = Off)
- **OneTime Auth:** This feature should be enabled when using Two Factor Authentication with the One Time Password scheme enabled. When enabled, the One Time Password will be valid for the time specified under the OneTime Auth Timer parameter. (Default = Off)
- **OneTime Auth Timer:** When the OneTime Auth parameter is enabled, this parameter determines how long (in minutes) the One Time Password will be valid. (Default = 5 Minutes)
- **Ping Test (Ping RADIUS Servers):** Allows you to ping IP addresses or domain names that have been defined via the RADIUS Parameters menus in order to check that a valid IP address or domain name has been entered.

Notes:

- *In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
- *In addition to the Ping Test feature, the /TEST command in the Text Interface or the "Test" option in the Web Browser Interface can also be used to ping any user defined IP address in order to make certain that the IP address is responding.*

6.6.10.1. Dictionary Support for RADIUS

The RADIUS dictionary file can allow you to define a user and assign command access rights and port access rights from a central location.

The RADIUS dictionary file, "dictionary.wti" can be found under the "downloads" tab on the product information page at wti.com. To install the dictionary file on your RADIUS server, please refer to the documentation provided with your server; some servers will require the dictionary file to reside in a specific directory location, others will require the dictionary file to be appended to an existing RADIUS dictionary file.

The WTI RADIUS dictionary file provides the following commands:

- **WTI-Super** - Sets the command access level for the user. This command provides the following arguments:
 - 0 = ViewOnly
 - 1 = User
 - 2 = SuperUser
 - 3 = Administrator

For example, in order to set command access level to "SuperUser", the command line would be:

WTI-Super="2"

- **WTI-Port-Access** - Determines which port(s) the user will be allowed to access. This command provides an argument that consists of a three character string, with one character for each SRM Serial Port. The following options are available for each port:
 - 0 = Off (Deny Access)
 - 1 = On (Allow Access)

For example, to allow access to Serial Ports 1 and 2, the command line would be:

WTI-Port-Access="110"

Example:

The following command could be used to set the command access level to "User", allow access to Serial Ports 1 and 27:

```
tom  Auth-Type:=Local, User-Password=="tom1"  
    Login-Service=Telnet,  
    Login-TCP-Port=Telnet,  
    User-Name="HARRY-tom",  
    WTI-Super="1",  
    WTI-Port-Access="110",
```

6.6.11. Email Messaging Parameters

The Email Messaging menu is used to define parameters for email messages that the SRM can send to notify you when an alarm is triggered. To define email message parameters, access the SRM Command Mode using a password that permits access to Administrator Level commands and then proceed as follows:

- **Text Interface:** Type `/N` (for IPv4 parameters) or `/N6` (for IPv6 parameters) and press **[Enter]** to access the Network Configuration Menu. Key in the number for the Email Messaging option and press **[Enter]** to display the Email Messaging Menu.
- **Web Browser Interface:** Place the cursor over the "Network Configuration" link on the left hand side of the screen. When the fly-out menu appears select either the link for IPv4 parameters or IPv6 parameters to display the Email Messaging Menu.

The Email Configuration menu offers the following options:

- **Enable:** Enables/Disables the Email Messaging feature. When disabled, the SRM will not be able to send email messages when an alarm is generated. (Default = Off)
- **SMTP Server:** This prompt is used to define the address of your SMTP Email server. (Default = undefined)
- **Port Number:** Selects the TCP/IP port number that will be used for email connections. (Default = 25)
- **Domain:** The domain name for your email server. (Default = undefined)
Note: *In order to use domain names, you must first define Domain Name Server parameters as described in Section 6.6.5.*
- **User Name:** The User Name that will be entered when logging into your email server. (Default = undefined)
- **Password:** The password that will be used when logging into your email server. (Default = undefined)
- **Auth Type:** The Authentication type; the SRM allows you to select None, Plain, Login, or CRAM-MD5 Authentication. (Default = None)
- **From Name:** The name that will appear in the "From" field in email sent by the SRM. (Default = undefined)
- **From Address:** The email address that will appear in the "From" field in email sent by the SRM. (Default = undefined)
- **To Address:** The address(es) that will receive email messages generated by the SRM. Note that up to three "To" addresses may be defined, and that when Alarm Configuration parameters are selected as described in Section 7, you may then designate these addresses as recipients for email messages that are generated by the alarms. (Default = undefined)
- **Send Test Email:** Sends a test email, using the parameters that are currently defined for the Email configuration menu.

6.7. Save User Selected Parameters

It is strongly recommended to save all user-defined parameters to a file as described in Section 13. This will allow quick recovery in the event of accidental deletion or reconfiguration of port parameters.

When changing configuration parameters via the Text Interface, make certain that the SRM has saved the newly defined parameters before exiting from command mode. To save parameters, press the **[Esc]** key several times until you have exited from all configuration menus and the SRM displays the "Saving Configuration" menu and the cursor returns to the command prompt. If newly defined configuration parameters are not saved prior to exiting from command mode, then the SRM will revert to the previously saved configuration after you exit from command mode.

6.7.1. Restore Configuration

If you make a mistake while configuring the SRM unit, and wish to return to the previously saved parameters, the Text Interface's "Reboot System" command (**/I**) offers the option to reinitialize the unit using previously backed up parameters. This allows you to reset the unit to previously saved parameters, even after you have changed parameters and saved them.

Notes:

- *The SRM will automatically backup saved parameters once a day, shortly after Midnight. This configuration backup file will contain only the most recently saved SRM parameters, and will be overwritten by the next night's daily backup.*
- *When the **/I** command is invoked, a submenu will be displayed which offers several Reboot options. Option 4 is used to restore the configuration backup file. The dates shown next to Option 4 indicates the date that you last changed and saved unit parameters.*
- *If the daily automatic configuration backup has been triggered since the configuration error was made, and the previously saved configuration has been overwritten by newer, incorrect parameters, then this function will not be able to restore the previously saved (correct) parameters.*

To restore the previously saved configuration, proceed as follows:

1. Access command mode via the Text Interface, using a username/password that permits access to Administrator level commands.
2. At the SRM command prompt, type **/I** and press **[Enter]**. The SRM will display a submenu that offers several different reboot options.
3. At the submenu, you may choose either Item 4 (Reboot & Restore Last Known Working Configuration.) Type **4**, and then press **[Enter]**.
4. The SRM will reboot and previously saved parameters will be restored.

7. Alarm Configuration

When properly configured, the SRM can monitor temperature readings, ping command response and a number of other factors at network installation sites and log this information for future review. When any monitored condition exceeds user-defined trigger levels, the SRM can also notify support personnel via Email, Syslog Message or SNMP trap.

Notes:

- *In order to send alarm notification via email, email addresses and parameters must first be defined as described in Section 6.6.11. Email alarm notification will then be sent for all alarms that are enabled as described in this Section.*
- *In order to send alarm notification via Syslog Message, a Syslog address must first be defined as described in Section 6.6.2. Once the Syslog address has been defined, Syslog Messages will be sent for every alarm that is discussed in this Section, providing that the Trigger Enable parameter for the alarm has been set to "On."*
- *In order to send alarm notification via SNMP Trap, SNMP Trap parameters must first be defined as described in Section 6.6.7. Once SNMP Trap Parameters have been defined, SNMP Traps will be sent for every alarm that is discussed in this Section, providing that the Trigger Enable parameter for the alarm has been set to "On."*
- *After defining parameters via the Text Interface, make certain to press the **[Esc]** key several times to completely exit from the configuration menu and save newly defined parameters. When parameters are defined via the Text Interface, newly defined parameters will not be saved until the "Saving Configuration" message is displayed.*

To configure the SRM's Alarm functions, access the command mode using a password that allows Administrator level and then activate the Alarm Configuration menu (in the Text Interface, type **/AC** and press **[Enter]**; in the Web Browser Interface, click on the "Alarm Configuration" link.)

7.1. The Over Temperature Alarms

The Over Temperature Alarms can inform you when temperatures inside your equipment rack reach or exceed user specified trigger levels. There are two separate Over Temperature Alarms; the Initial Threshold alarm and the Critical Threshold Alarm.

Typically, the Initial Threshold alarm is used to provide notification when temperatures reach a point where you *might* want to investigate, whereas the Critical Threshold alarm is used to provide notification when temperatures approach a level that may harm equipment or inhibit performance. The trigger for the Initial Threshold alarm is generally set lower than the Critical Threshold alarm.

Notes:

- *In order for the SRM to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.6.11.*
- *In order for the SRM to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.6.2.*
- *In order for the SRM to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.6.7.*

To configure the Over Temperature Alarms, access the SRM command mode using a password that permits Administrator Level commands, and then use the Alarm Configuration menu to select the desired alarm feature.

Note that both the Initial Threshold menus and Critical Threshold menus offer essentially the same set of parameters, but parameters defined for each alarm are separate and unique. Therefore, parameters defined for the Critical Threshold Alarm will not be applied to the Initial Threshold Alarm and vice versa. Both the Over Temperature (Initial Threshold) alarm and the Over Temperature (Critical Threshold) alarm offer the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

Notes:

- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all SRM alarms. For example, if the Lost Communication Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers)", then all other SRM alarms will also be enabled.*

- **Alarm Set Threshold:** The trigger level for this alarm. When temperature exceeds the Alarm Set Threshold, the SRM can send an alarm (if enabled.) (Initial Threshold: Default = 110°F or 43°C, Critical Threshold: Default = 120°F or 49°C)

Note: *The Alarm Set Threshold value must be greater than the Alarm Clear Threshold value. The SRM will not allow you to define an Alarm Clear Threshold value that is higher than the Alarm Set Threshold.*

- **Alarm Clear Threshold:** Determines how low the temperature must drop in order for the Alarm condition to be cancelled. (Initial Threshold: Default = 100°F or 38°C, Critical Threshold: Default = 110°F or 43°C)

Note: *The System Parameters menu is used to set the temperature format for the SRM unit to either Fahrenheit or Celsius as described in Section 6.2.*

- **Resend Delay:** Determines how long the SRM will wait to resend an email message generated by this alarm, when the initial attempt to send notification was unsuccessful. (Default = 60 Minutes)
 - **Notify Upon Clear:** When this item is enabled, the SRM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the SRM will send initial notification when it detects that the temperature has exceeded the trigger value, and then send a second notification when it determines that the temperature has fallen below the trigger value. (Default = On)
 - **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
 - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses, defined via the "Email Messages" menu (see Section 6.6.11,) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)
- Note:** *If Email addresses have been previously defined, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Over Temperature (Initial)" or "Alarm: Over Temperature (Critical)")

7.2. The Ping-No-Answer Alarm

The Ping-No-Answer Alarm can be used to provide notification when a device at a target IP address fails to respond to a ping command. When properly configured and enabled, the Ping-No-Answer Alarm can promptly notify network administrators and support personnel when a target device appears to have malfunctioned, allowing quick response to equipment problems that could potentially interfere with network communication.

The following sections describe the procedure for setting up the Ping-No-Answer alarm:

7.2.1. Ping-No-Answer Notification

When properly configured, SRM units can provide notification when a device at a user-specified IP address fails to respond to a ping command. When one of the user-defined IP addresses fails to answer a Ping command, the SRM can provide notification via Email, Syslog Message or SNMP Trap.

Notes:

- *In order for the Ping-No-Answer Alarm to work properly, your network and/or firewall, as well as the device at the target IP address, must be configured to allow ping commands.*
- *In order for this alarm to function, at least one target IP Address for the Ping No Answer Alarm must be defined as described in Section 7.2.1.1.*
- *In order for the SRM to provide Email alarm notification, communication parameters must first be defined as described in Section 6.6.11.*
- *In order for the SRM to provide Syslog Message notification, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.6.2.*
- *In order for the SRM to provide SNMP Trap notification when this alarm is triggered, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.6.7.*

7.2.1.1. Defining Ping No Answer IP Addresses

In order for the Ping No Answer Alarm to function, you must first define at least one target IP address. To define target IP addresses for the Ping-No-Answer Alarm, access command mode using an account that permits Administrator Level commands and then proceed as follows:

- **Text Interface:** At the command prompt, type `/PNA` and then press **[Enter]** to display the Ping No Answer menu. Type 2 and press **[Enter]** to add a target IP address for the Ping No Answer Alarm.
- **Web Browser Interface:** Click the "Ping No Answer Configuration" link, located on the left hand side of the screen to display the Ping No Answer Configuration Menu. Click on the "Add Ping No Answer" link to define a target IP address(es) for the Ping No Answer Alarm.

Note that both the Text Interface and the Web Browser Interface include menu options that allow you to either View previously defined Ping No Answer IP Addresses, add new Ping No Answer Addresses, Modify previously defined Ping No Answer IP Addresses or delete previously defined Ping No Answer IP addresses.

After one or more Ping No Answer IP Addresses have been defined as described in this section, the Ping No Answer Alarm function can then be enabled and configured as described in Section 7.2.1.2. Up to 54 Ping No Answer IP Addresses can be defined. The Add Ping No Answer menu is used to define the following parameters for each new Ping No Answer IP Address:

- **IP Address or Domain Name:** The IP address or Domain Name for the target device. When the device at this address fails to respond to the Ping command, the Ping No Answer Alarm can provide user notification. (Default = undefined)

Notes:

- *In order to use Domain Names, you must first define DNS parameters as described in Section 6.6.5.*
 - *The target IP Address can be entered in either IPv4 format or IPv6 format. In the text interface, a the "IP Address or Domain Name" submenu is used to select either IPv4 or IPv6 protocol. In the Web Browser Interface, a drop down menu is used to select the desired protocol.*
 - **Protocol:** Allows definition of an IPv4 format IP Address or an IPv6 format IP Address. Note that if desired, both an IPv4 and an IPv6 format IP Address may be defined. (Default = IPv4)
- Note:** *In the Text Interface, the protocol is specified via the IP Address or Domain Name prompt.*
- **Ping Interval:** Determines how often the Ping command will be sent to the selected IP Address. The Ping Interval can be any whole number, from 1 to 3,600 seconds. (Default = 60 Seconds)
- Note:** *If the Ping Interval is set lower than 20 seconds, it is recommended to define the "IP Address or Domain Name" parameter using an IP Address rather than a Domain Name. This ensures more reliable results in the event that the Domain Name Server is unavailable.*
- **Interval After Failed Ping:** Determines how often the Ping command will be sent after a previous Ping command receives no response. (Default = 10 Seconds)
 - **Ping Delay After PNA Action:** Determines how long the SRM will wait to send additional ping commands, after the Ping No Answer Alarm has been triggered. (Default = 15 Minutes)
 - **Consecutive Failures:** Determines how many consecutive failures of the Ping command must be detected in order to trigger the Ping No Answer Alarm. For example, if this value is set to "3", then after three consecutive Ping failures, the Ping No Answer Alarm will be triggered. (Default = 5)

- **PNA Action:** Determines how the Ping No Answer Alarm will react when this IP address fails to respond to a ping. If "Continuous Alarm" is selected, the SRM will continue to generate new alarms until the Ping No Answer Alarm is cleared. If "Single Alarm" is generated, the SRM will generate a single alarm and will not generate additional alarms until a successful ping operation is completed and then another Ping No Answer condition is detected. (Default = Continuous Alarm)
- **Ping Test:** Sends a test Ping command to this IP Address.

Notes:

- *In order for the Ping Test feature to work properly, your network and/or firewall, as well as the device at the target IP address, must be configured to allow ping commands.*
- *After defining or editing Ping No Answer IP Addresses, make certain to save the changes before proceeding. In the Web Browser Interface, click on the "Add Ping No Answer" button to save parameters; in the Text Interface, press the [Esc] key several times until the "Saving Configuration" message is displayed and the cursor returns to the command prompt.*

7.2.1.2. Configuring the Ping No Answer Alarm

To configure the Ping-No-Answer Alarm, you must access command mode using a password that permits Administrator Level commands. The Ping-No-Answer alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

Notes:

- *In order for this alarm to function, at least one target IP Address for the Ping No Answer Alarm must be defined as described in Section 7.2.1.1.*
- *To cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter to Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all SRM alarms. For example, if the Ping No Answer Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers)", then all other SRM alarms will also be enabled.*
- **Resend Delay:** Determines how long the SRM will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
- **Notify Upon Clear:** When this item is enabled, the SRM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the SRM will send initial notification when it detects that a Ping command has failed, and then send a second notification when it determines that the IP address is again responding to the Ping command. (Default = On)

- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.6.11) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)

Note: *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages that are generated by this alarm. (Default = "Alarm: Ping No Answer")

7.3. The Serial Port Invalid Access Lockout Alarm

The Serial Port Invalid Access Lockout Alarm can provide notification when the SRM has locked the serial SetUp port due to repeated, invalid attempts to access command mode via the port. Normally, the Invalid Access Lockout feature (discussed in Section 6.2.2) can lock the serial port whenever the unit detects that the user-defined threshold for invalid access attempts has been exceeded. When the Serial Port Invalid Access Lockout Alarm is properly configured and enabled, the unit can also provide notification via Email, SYSLOG message or SNMP Trap when a serial port lockout occurs.

Notes:

- *Note that Serial Port Invalid Access Lockout Alarm is only intended to provide notification when the Invalid Access Lockout feature has locked the serial SetUp port. To apply the Invalid Access Lockout feature to the Network Port, please refer to Section 6.6.2.*
- *If desired, the SRM can be configured to count Invalid Access attempts at the serial SetUp port, and provide notification when the counter exceeds a user defined trigger level, without actually locking the serial SetUp port. To do this, enable the Invalid Access Lockout Alarm as described here, but when you configure Invalid Access Lockout parameters as described in Section 6.2.2, set the Lockout Attempts and Lockout Duration as you would normally, and then set the "Lockout Enable" parameter to "Off."*
- *In order for the SRM to provide Email alarm notification, communication parameters must first be defined as described in Section 6.6.11.*
- *In order for the SRM to provide Syslog Message notification, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.6.2 and Section 10.*
- *In order for the SRM to provide SNMP Trap notification when this alarm is triggered, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.6.7 and Section 11.*

To configure the Serial Port Invalid Access Lockout Alarm, you must access the SRM command mode using a password that permits Administrator Level commands. The Invalid Access Lockout alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

Note:

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify on Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all SRM alarms. For example, if the Invalid Access Lockout Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers)", then other SRM alarms will also be enabled.*

- **Resend Delay:** Determines how long the SRM will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)
- **Notify Upon Clear:** When this item is enabled, the SRM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the SRM will send initial notification when it detects that an Invalid Access Lockout has occurred, and then send a second notification when it determines that the ports have been unlocked. (Default = On)
- **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
- **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.6.11) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)

Note: *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*

- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Invalid Access Lockout")

7.4. The Power Cycle Alarm

The Power Cycle Alarm can provide notification when all input power to the SRM unit is lost and then restored. When the power supply is lost and then restored, the SRM can provide notification via Email, Syslog Message or SNMP Trap.

Notes:

- *In order for the SRM to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.6.11.*
- *In order for the SRM to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.6.2 and Section 10.*
- *In order for the SRM to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.6.7 and Section 11.*

To configure the Power Cycle Alarm, you must access the SRM command mode using a password that permits Administrator Level commands. The Power Cycle Alarm configuration menu offers the following parameters:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

Note:

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
 - *The Trigger Enable, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all SRM alarms. For example, if the Power Cycle Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers), then other SRM alarms will also be enabled.*
 - **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
 - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.6.11) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)
- Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: Power Cycle")

7.5. The No Dialtone Alarm

The No Dialtone Alarm enables the SRM to monitor the phone line connected to the SRM phone port, and then provide notification if the SRM detects that the phone line is dead or no dialtone is present.

When the No Dialtone Alarm is enabled the SRM will monitor the telephone line checking for a dialtone. If no dialtone is detected for the duration of the currently defined "Reset/No Dialtone Interval" value, the No Dialtone Alarm can provide notification via email using a network connection. In the event that the SRM unit is not connected to a network cable, the SRM will also create an entry in the Alarm Log, indicating that the No Dialtone Alarm has been triggered.

Notes:

- *In order for this alarm to function, the No Dialtone Alarm must first be enabled and the No Dialtone Interval must be defined. To enable the No Dialtone Alarm and define the No Dialtone Interval, please refer to Section 6.5.2.3.*
- *In order for the SRM to provide alarm notification via Email, communication parameters must first be defined as described in Section 6.6.11.*
- *In order for the SRM to provide alarm notification via Syslog Message, Syslog parameters must first be defined and Syslog Messages must be enabled as described in Section 6.6.2 and Section 10.*
- *In order for the SRM to provide alarm notification via SNMP Trap, SNMP parameters must first be defined, and SNMP Traps must be enabled as described in Section 6.6.7 and Section 11.*
- *If desired, an external alarm device can be connected to the Switched Contact (see Figure 2.2.) on the SRM's back panel. When an external alarm is connected to the SRM's Switched Contact port, the external audible alarm will be activated when the No Dialtone Alarm is triggered.*

The configuration menu for the No Dialtone Alarm allows the following parameters to be defined:

- **Trigger Enable:** Enables/Disables the trigger for this alarm. When Disabled, this alarm will be suppressed. (Default = On)

Note:

- *When an alarm is generated, to cancel an alarm without correcting the condition that caused the alarm, simply toggle the Trigger Enable parameter Off and then back On again.*
- *The Trigger Enable, Notify Upon Clear, Email Message and Address 1, 2 and 3 Parameters all include "Copy to All Triggers" options that allow you to enable/disable the corresponding parameter for all SRM alarms. For example, if the No Dialtone Alarm's Trigger Enable parameter is set to "On (Copy to All Triggers)", then all other SRM alarms will also be enabled.*
- **Resend Delay:** Determines how long the SRM will wait to resend an email message generated by this alarm, when the initial attempt to send the notification was unsuccessful. (Default = 60 Minutes)

- **Notify Upon Clear:** When this item is enabled, the SRM will send additional notification when the situation that caused the alarm has been corrected. For example, when Notify Upon Clear is enabled, the SRM will send initial notification when it detects that the dialtone for the external modem has been lost, and then send a second notification when it determines that the dialtone has been restored. (Default = On)
 - **Email Message:** Enables/Disables email notification for this alarm. (Default = On)
 - **Address 1, 2, and 3:** These parameters are used to select which of the three email addresses defined via the "Email Messages" menu (see Section 6.6.11) will receive the email alarm notification messages generated by this alarm. The Address parameters can be used to select one, or any combination of the addresses defined via the Email Messages menu. (Default = All On)
- Note:** *If Email addresses have been previously specified, then the text under the parameters will list the current, user defined email addresses.*
- **Subject:** This parameter is used to define the text that will appear in the "Subject" field for all email notification messages generated by this alarm. (Default = "Alarm: No Dial Tone")

8. The Status Screens

The Status Screens are used to display status information about the SRM serial ports, Network Port, Temperature Log, Alarm Log and Audit Log. The Status Screens are available via both the Text Interface and Web Browser Interface.

8.1. Product Status

The Product Status Screen lists the model number, power rating, product serial number and other information regarding the SRM unit. To display the Product Status Screen via the Text Interface, type `/J *` and then press **[Enter]**. To display the Product Status Screen via the Web Browser Interface, click on the "Product Status" link.

Note: *The Information provided by the Product Status Screen is intended mainly to assist WTI support personnel with the diagnosis of user equipment problems.*

8.2. The Network Status Screen

The Network Status screen shows activity at the SRM's virtual network ports. To view the Network Status Screen, you must access command mode using a password that permits access to Administrator Level commands.

To display the Network Status Screen via the Text Interface, type `/sn` and press **[Enter]**. To display the Network Status Screen via the Web Browser Interface, click on the Network Status link.

8.3. The Port Status Screen

The Port Status screen shows the current status of the SRM's Serial SetUp Port, Serial Modem Port and Modem, including the user-defined port name and port mode for each Serial Port, as well as the buffer count, connection status and the names of any user's currently accessing these ports.

Note:

- *In the default state, Port 2 (the Serial Modem Port) is connected to Port 3 (the internal Modem.)*
- *When Port Status is viewed by an account with "Administrator" or "SuperUser" command access, all SRM Serial Ports are listed.*
- *When Port Status is viewed by an account with "User" or "ViewOnly" command access, then the screen will list only the Serial Ports that are allowed by that account.*
- *The Port Status Screen also shows the current status of the SRM's Internal Modem Port.*

To view the Port Status Screen via the Text Interface, type `/s` and press **[Enter]**. To view the Port Status Screen via the Web Browser Interface, place the cursor over the "Port Status" link; when the flyout menu appears, click on the "Serial Port Status" link.

Note: *Port 1 is the System SetUp Port, Port 2 is the Modem Port and Port 3 is the Internal Modem.*

8.4. The Port Diagnostics Screen

The Port Diagnostics Screen provides more detailed information about each serial port. To display the Port Diagnostics Screen, access the Text Interface command mode and type `/SD` **[Enter]**.

Note: *The Port Diagnostics Screen is only available via the Text Interface.*

When the `/SD` command is invoked by an Administrator or SuperUser level account, the Port Diagnostics Screen will display the status of all ports. If the `/SD` command is invoked by a User or ViewOnly level account, then the Port Diagnostics Screen will only display the status of the ports that are specifically allowed by that account.

8.5. The Alarm Status Screen

The Alarm Status Screen lists all available user-defined alarms and indicates whether or not each alarm has been triggered. The resulting screen will display "Yes" (or 1) for alarms that have been triggered or "No" (or 0) for alarms that have not been triggered. If desired, the `/AS` command line can also include an optional alarm argument that will cause the unit to display the status of one individual alarm. For a list of alarm arguments, please refer to Section 15.3.1.

8.6. The Port Parameters Screens

The /W (Who) command displays more detailed information about an individual SRM serial port. Rather than listing general connection information for all ports, the Port Parameters screen lists all defined parameters for a specific port.

When the /W command is invoked by an Administrator or SuperUser level account, it can be used to display parameters for all SRM Serial Ports, plus the Network Port. If the /W command is invoked by a User or ViewOnly level account, then it will only display parameters for the Serial Ports that are specifically allowed for that account, and will not display parameters for the Network Port.

The /W command uses the following format:

/W x [Enter]

Where **xx** is the desired port number. If the /W command is invoked at a serial port, by a user with access to Administrator or SuperUser level commands, then the letter "N" can be entered as the command argument to display parameters for the Network Port.

Note:

- *Port 1 is the System SetUp Port, Port 2 is the Modem Port and Port 3 is the Internal Modem.*
- *The Port Parameters screens are only available via the Text Interface.*
- *When the /W command is invoked by an Administrator level account which has accessed command mode via the Network Port , all Network Port Parameters will be displayed..*
- *When the /W command is invoked by a SuperUser level account which has accessed command mode via the Network Port, only the Sequence Disconnect, Logoff Character, and Accept Break option will be displayed.*

8.7. The Event Logs

The Event Logs can be used to review recent user activity, alarm events and temperature trends that have been recorded by the SRM unit. In order to view, download or erase the event logs, you must access command mode using a password that permits Administrator or SuperUser level commands.

To access the Event Logs via the Text Interface, type `/L`, press **[Enter]** and then select the desired option from the resulting submenu. To access the Event Logs via the Web Browser Interface, place the cursor over the "Logs" link on the left hand side of the screen, wait for the flyout menu to appear, and then select the desired option.

Note: *Although both the Text Interface and Web Browser Interface allow you to display or download the Event Logs, the Event Logs can only be erased via the Text Interface.*

8.7.1. The Audit Log

The Audit Log provides a record of most command activity at the SRM unit, including port connections and disconnections, login and logout activity. Note however that the Audit Log does not include user information regarding access to configuration menus or status screens.

8.7.2. The Alarm Log

The Alarm Log provides a record of all events that were initiated by a SRM alarm function.

8.7.3. The Temperature Log

The temperature log provides a record of SRM temperature readings, in reverse chronological order, with the most recent events appearing at the top of the list.

9. Telnet & SSH Functions

9.1. Network Port Numbers

Whenever an inbound Telnet or SSH session connects to the SRM's serial SetUp port, the Port Status Screen and Port Diagnostics Screen will indicate that the serial port is presently connected to Port "**Nn**" (where "**N**" indicates a network connection, and "**n**" is a number that lists the logical Network Port being used; for example, "**N11**".) This "**Nn**" number is referred to as the logical Network Port Number.

9.2. SSH Encryption

In addition to standard Telnet protocol, the SRM also supports SSH connections, which provide secure, encrypted access via network. In order to communicate with the SRM using SSH protocol, your network node must include an appropriate SSH client.

Note that when the /K (Send SSH Key) command is invoked, the SRM can also provide you with a public SSH key, which can be used to streamline connection to the SRM when using SSH protocol.

Although you can establish an SSH connection to the unit *without* the public key, the public key provides validation for the SRM, and once this key is supplied to the SSH client, the client will no longer display a warning indicating that the SRM is not a recognized user when the client attempts to establish a connection.

The /K command uses the following format:

/K <k> [Enter]

Where **k** is an argument that determines which type of public key will be displayed, and the **k** argument offers the following options:

1. SSH1
2. SSH2 RSA
3. SSH2 DSA

For example, to obtain the public SSH key for an SSH2 RSA client, type /K 2 and then press [Enter].

Note: *Although the SRM does not support SSH1, the /K 1 command will still return a key for SSH1.*

9.3. Creating an Outbound Telnet Connection

The SRM includes a `/TELNET` command, that can be used to create an outbound Telnet connection. In order to use the `/TELNET` command, you must access the SRM's Text Interface command mode using an account that permits Telnet Access and Outbound Access, via one of the SRM's Serial RS232 Ports as described below.

Notes:

- *In order for the `/TELNET` command to function, Telnet Access and Outbound Service Access must be enabled for your user account as described in Section 6.4.*
- *The `/TELNET` command is only available via the Text Interface.*
- *If you have logged in via the Network Port, the `/TELNET` command will not function unless Outbound Access has been enabled as described in Section 6.6.2.*

To create an outbound Telnet connection, access the Text Interface via a free Serial Port, using an account that permits Telnet Access and Outbound Access and then invoke the `/TELNET` command using the following format:

`/TELNET <ip> [port] [Enter]`

Where:

ip Is the target IP address.

port Is an optional argument which can be included to indicate the target port at the IP address.

For example, to create an outbound Telnet connection to port 2000 at IP Address 255.255.255.255, access the Text Interface command mode via a free SRM Serial Port using an account that permits Telnet Access and Outbound Access and invoke the `TELNET` command as follows:

`/TELNET 255.255.255.255 2000 [Enter]`

9.4. Creating an Outbound SSH Connection

The SRM's /SSH command can be used to create an outbound SSH connection. In order to use the /SSH command, you must access the SRM's Text Interface command mode using an account that permits SSH Access and Outbound Access, via one of the SRM's Serial RS232 Ports as described below.

Notes:

- *In order for the /SSH command to function, SSH Access and Outbound Service Access must be enabled for your user account as described in Section 6.4.*
- *The /SSH command is only available via the Text Interface.*
- *If you have logged in via the Network Port, the /SSH command will not function.*

To create an outbound SSH connection, access the Text Interface via a free Serial Port, using an account that permits SSH Access and Outbound Access and then invoke the /SSH command using the following format:

```
/SSH <ip> -l <username> [Enter]
```

Where:

- ip** Is the target IP address.
- l** (Lowercase letter "l") Indicates that the next argument will be the log on name.
- username** Is the username that you wish to use to log in to the target device.

For example, to create an outbound SSH connection to a device at IP Address 255.255.255.255, with the username "employee", access the Text Interface command mode via a free SRM Serial Port using an account that permits SSH Access and Outbound Access and invoke the SSH command as follows:

```
/SSH 255.255.255.255 -l employee [Enter]
```

10. Syslog Messages

The Syslog feature can create log records of each Alarm Event. As these event records are created, they are sent to a Syslog Daemon, located at an IP address defined via the Network Parameters menu.

10.1. Configuration

In order to employ this feature, you must set the real-time clock and calendar via the System Parameters Menu, and define the IP address for the Syslog Daemon via the Network Port Configuration menu.

To configure the Syslog function, please proceed as follows:

1. **Access command mode:** Note that the following configuration menus are only available to accounts that permit Administrator level commands.
2. **System Parameters Menu:** Access the System Parameters Menu as described in Section 6.2, then set the following parameters:
 - a) **Set Clock and Calendar:** Set the Real Time Clock and Calendar and/or configure and enable the NTP server feature.
3. **Network Parameters Menu:** Access the Network Parameters Menu as described in Section 6.6, then set the following parameters:
 - a) **Syslog IP Address:** Determine the IP address for the device that will run the Syslog Daemon, then use the Network Port Configuration menu to define the IP address for the Syslog Daemon.

Notes:

- *The Network Parameters Menu allows the definition of IP addresses for both a primary Syslog Daemon and an optional secondary Syslog Daemon.*
 - *The Syslog Address submenu in the Text Interface includes a Ping Test function that can be used to ping the user-selected Syslog IP Address to verify that a valid IP address has been entered. In order for the Ping Test feature to function, your network and/or firewall must be configured to allow ping commands.*
4. **Syslog Daemon:** In order to capture messages sent by the SRM, a computer must be running a Syslog Daemon (set to UDP Port 514) at the IP address(es) specified in Step 3 above.

Once the Syslog Address is defined, Syslog messages will be generated whenever one of the alarms discussed in Section 7 is triggered.

11. Operation via SNMP

If SNMP Access Parameters have been defined as described in Section 6.6.6, then you will be able to manage user accounts, control power and reboot switching and display unit status via SNMP. This section describes SNMP communication with the SRM unit, and lists some common commands that can be employed to manage users, control switching and reboot actions and display unit status.

11.1. SRM SNMP Agent

The SRM's SNMP Agent supports various configuration, control, status and event notification capabilities. Managed objects are described in the WTI-CONSOLE-MIB.txt document, which can be found on the WTI web site (<http://www.wti.com>). The WTI-CONSOLE-MIB.txt document can be compiled for use with your SNMP client.

11.2. SNMPv3 Authentication and Encryption

The major limitations of SNMPv2 were the failure to include proper username/password login credentials (v2 only used a password type of login, i.e., community name) and the lack of support for encryption of transmitted data. SNMPv3 addresses both of these shortcomings.

For SNMPv3, the SRM supports two forms of Authentication/Privacy: Auth/noPriv which requires a username/password, but does not encrypt data going over the internet and Auth/Priv which requires a username/password AND encrypts the data going over the internet using DES or AES (in the case of the SRM, the default encryption format for SNMPv3 is DES.) For the Password protocol, the SRM supports either MD5 or SHA1.

11.3. Configuration via SNMP

SRM User accounts can be viewed, created, modified, and deleted via SNMP. User accounts are arranged in a table of 128 rows, and indexed 1-128. User account parameters, as seen through the SNMP, are summarized below.

- **userTable::userName** – 32 character username
- **userTable::userPasswd** – 16 character password
- **userTable::userAccessLevel** – Account access level.
 - 0 – View Access
 - 1 – User Access
 - 2 – Superuser Access
 - 3 – Administrator Access
- **userTable::userPortAccess** – A string of up to 3 characters, with one character for each of the 3 possible serial ports on the SRM unit. A '0' indicates that the account **does not** have access to the port, and a '1' indicates that the user **does** have access to the port.

Note: *The number of ports specified in the userPortAccess string must not exceed the number of serial ports available on your SRM unit. If the userPortAccess string specifies more serial ports than are available on the unit, an error message will be generated.*

- **userTable::userSerialAccess** – Access to the serial interface
 - 0 – No access
 - 1 – Access
- **userTable::userTelnetSshAccess** – Access to the Telnet/SSH interface
 - 0 – No access
 - 1 – Access
- **userTable::userOutboundTelSshAccess** – Access to Outbound Telnet/SSH
 - 0 – No access
 - 1 – Access
- **userTable::userWebAccess** – Access to the Web interface
 - 0 – No access
 - 1 – Access
- **userTable::userCallbackNum** – 32 character callback number for account
- **userTable::userSubmit** – Set to 1 to submit changes.

11.3.1. Viewing Users

To view users, issue a GET request on any of the user parameters for the index corresponding to the desired user.

11.3.2. Adding Users

For an empty index, issue a SET request on the desired parameters. Minimum requirement is a username and password to create a user, all other parameters will be set to defaults if not specified. To create the user, issue a SET request on the userSubmit object.

11.3.3. Modifying Users

For the index corresponding to the user you wish to modify, issue a SET request on the desired parameters to be modified. Once complete, issue a SET request on the userSubmit object.

11.3.4. Deleting Users

For the index corresponding to the user you wish to delete, issue a SET request on the username with a blank string. Once complete, issue a SET request on the userSubmit object.

11.4. Configuring Serial Ports

Commands can be issued to set certain serial port configuration parameters via SNMP. Ports are arranged in a table of three rows, with one row for each serial port. Serial port parameters are described below.

- **portTable::portID** – String indicating the serial port's ID
- **portTable::portStatus** - Shows the connection status of each port. If a port is connected, the portStatus object will return the number of the other port in the connection pair.
 - free** - Disconnect port.

11.5. Viewing Unit Status via SNMP

Status of various components of the SRM can be retrieved via SNMP.

11.5.1. System Status - Ethernet Port Mac Addresses

The Mac Address for the Ethernet Port can be displayed using the command below:

- `environmentUnitTable::environmentMacEth0` The Mac Address for the Ethernet Port.

11.5.2. Unit Temperature Status

The temperature status can be retrieved for the SRM unit. The `environmentUnitTable` contains one row.

- `environmentUnitTable::environmentUnitTemperature` – The temperature of the SRM unit.
- `environmentUnitTable::environmentUnitName` – Returns the specific model number for the SRM unit.

11.5.3. Alarm Status

The status of the SRM unit's alarm functions can be retrieved and displayed using the following commands:

Notes:

- *When an alarm status command returns a zero (0), this indicates that the alarm is inactive.*
- *When an alarm status command returns a one (1), this indicates that the alarm is active (triggered.)*
- `alarmTables::alarmOverTemperatureInitial` - Displays the status of the Over Temperature (Initial) Alarm.
- `alarmTables::alarmOverTemperatureCritical` - Displays the status of the Over Temperature (Critical) Alarm.
- `alarmTables::alarmPingNoAnswer` - Displays the status of the Ping-No-Answer Alarm.
- `alarmTables::alarmInvalidAccessLockout` - Displays the status of the Serial Port Invalid Access Lockout Alarm.
- `alarmTables::alarmPowerCycle` - Displays the status of the Power Cycle Alarm.
- `alarmTables::alarmNoDialtone` - Displays the status of the No Dialtone Alarm.

11.6. Sending Traps via SNMP

Traps that report various unit conditions can be sent to an SNMP Management Station from the SRM. The following traps are currently supported.

- **WarmStart** Trap – Trap indicating a warm start
- **ColdStart** Trap – Trap indicating a cold start
- **Test** Trap – Test trap invoked by user via the Text Interface (CLI)

The SRM can send an SNMP trap to notify you when any of the available SRM alarm functions have been triggered. In all cases except the Power Cycle Alarm, there will be one trap sent when the alarm is triggered, and a second trap sent when the alarm is cleared. For more information on alarm functions, please refer to Section 7.

- **Alarm** Trap – Trap indicating an alarm condition. A trap with a unique enterprise OID is defined for the Invalid Access Lockout Alarm, under which specific trap-types are defined to indicate the setting or clearing of that particular alarm condition. There are separate traps for the Invalid Access Lockout Alarm. The Alarm includes a "Set Trap," which indicates that the alarm has been triggered, and a "Clear Trap," which indicates that the alarm has been cleared.
- **overTemperatureInitialSetTrap** - Indicates that the Over Temperature (Initial) Alarm has been triggered. The trap will also include a numerical value that indicates the current unit temperature.
- **overTemperatureInitialClearTrap** - Indicates that the Over Temperature (Initial) Alarm has been cleared.
- **overTemperatureCriticalSetTrap** - Indicates that the Over Temperature (Critical) Alarm has been triggered. The trap will also include a numerical value that indicates the current unit temperature.
- **overTemperatureCriticalClearTrap** - Indicates that the Over Temperature (Critical) Alarm has been cleared.
- **pingNoAnswerSetTrap** - Indicates that the Ping No Answer Alarm has been triggered. The trap will also include a numerical value that indicates the IP address of the device that failed to respond to the ping command.
- **pingNoAnswerClearTrap** - Indicates that the Ping No Answer Alarm has been cleared.
- **lockoutSetTrap** - Indicates that the Invalid Access Lockout Alarm has been triggered. The trap will also include a numerical value that indicates the number of the serial port where the lockout occurred.
- **lockoutClearTrap** - Indicates that the Invalid Access Lockout Alarm has been cleared.
- **powercycleSetTrap** - Indicates that the Power Cycle Alarm has been triggered (Note that there is no corresponding Clear Trap for the Power Cycle Alarm.)
- **noDialtoneSetTrap** - Indicates that the No Dialtone Alarm has been triggered.
- **noDialtoneClearTrap** - Indicates that the No Dialtone Alarm has been cleared.

12 Setting Up SSL Encryption

This section describes the procedure for setting up a secure connection via an HTTPS web connection to the SRM.

Note: *SSL parameters cannot be defined via the Web Browser Interface. In order to set up SSL encryption, you must contact the SRM via the Text Interface.*

There are two different types of HTTPS security certificates: "Self Signed" certificates and "Signed" certificates.

Self Signed certificates can be created by the SRM, without the need to go to an outside service, and there is no need to set up your domain name server to recognize the SRM. The principal disadvantage of Self Signed certificates, is that when you access the SRM command mode via the Web Browser Interface, the browser will display a message which warns that the connection might be unsafe. Note however, that even though this message is displayed, communication will still be encrypted, and the message is merely a warning that the SRM is not recognized and that you may not be connecting to the site that you intended.

Signed certificates must be created via an outside security service (e.g., VeriSign®, Thawte™, etc.) and then uploaded to the SRM unit to verify the user's identity. In order to use Signed certificates, you must contact an appropriate security service and set up your domain name server to recognize the name that you will assign to the SRM unit (e.g., service.wti.com.) Once a signed certificate has been created and uploaded to the SRM, you will then be able to access command mode without seeing the warning message that is normally displayed for Self Signed certificate access.

```
WEB ACCESS: [eth0] IPv4

HTTP:
1. Enable: On
2. Port: 80

HTTPS:
3. Enable: Off
4. Port: 443

SSL Certificates:
5. Common Name:
6. State or Province:
7. Locality:
8. Country:
9. Email Address:
10. Organization Name:
11. Organizational Unit:
12. Create CSR:
13. View CSR:
14. Import CRT:
15. Export Server Private Key:
16. Import Server Private Key:
17. Harden Web Security: On
18. TLS Mode: TLSv1

Enter: #<CR> to change,
      <ESC> to return to previous menu ...
```

Figure 12.1: Web Access Parameters (Text Interface Only)

12.1. Creating a Self Signed Certificate

To create a Self Signed certificate, access the Text interface via Telnet or SSH, using a password that permits access to Administrator level commands and then proceed as follows:

1. Type **/N** and press **[Enter]** to display the Network Parameters menu.
2. At the Network Parameters menu, type **23** and press **[Enter]** to display the Web Access menu (Figure 12.1.) Type **3** and press **[Enter]** and then follow the instructions in the resulting submenu to enable HTTPS access.
3. Next, use the Web Access menu to define the following parameters.

Note: *When configuring the SRM, make certain to define all of the following parameters. Although most SSL applications require only the Common Name, in the case of the SRM all of the following parameters are mandatory.*

- **5. Common Name:** A domain name, that will be used to identify the SRM unit. If you will use a Self Signed certificate, then this name can be any name that you choose, and there is no need to set up your domain name server to recognize this name. However, if you will use a Signed certificate, then your domain name server must be set up to recognize this name (e.g., service.yourcompanyname.com.)
- **6. State or Province:** The name of the state or province where the SRM unit will be located (e.g., California.)
- **7. Locality:** The city or town where the SRM unit will be located (e.g., Irvine.)
- **8. Country:** The two character country code for the nation where the SRM will be located (e.g., US.)
- **9. Email Address:** An email address, that can be used to contact the person responsible for the SRM (e.g., jsmith@yourcompany.com.)
- **10. Organizational Name:** The name of your company or organization (e.g., Yourcompanyname, Inc.)
- **11. Organizational Unit:** The name of your department or division; if necessary, any random text can be entered in this field (e.g., tech support.)

4. After you have defined parameters 5 through 11, type 12 and press **[Enter]** (Create CSR) to create a Certificate Signing Request. By default, this will overwrite any existing certificate, and create a new Self Signed certificate.
 - a) The SRM will prompt you to create a password. Key in the desired password (up to 16 characters) and then press **[Enter]**. When the SRM prompts you to verify the password, key it again and then press **[Enter]** once. After a brief pause, the SRM will return to the Web Access Menu, indicating that the CSR has been successfully created.
 - b) When the Web Access Menu is re-displayed, press **[Esc]** several times until you exit from the Network Parameters menu and the "Saving Configuration" message is displayed.
5. After the new configuration has been saved, test the Self Signed certificate by accessing the SRM via the Web Interface, using an HTTPS connection.
 - a) Before the connection is established, the SRM should display the warning message described previously. This indicates that the Self Signed certificate has been successfully created and saved.
 - b) Click on the "Yes" button to proceed. The SRM will prompt you to enter a user name and password. After keying in your password, the main menu should be displayed, indicating that you have successfully accessed command mode.

12.2. Creating a Signed Certificate

To create a Signed certificate, and eliminate the warning message, first set up your domain name server to recognize the Common Name (item 5) that you will assign to the unit. Next, complete steps one through five as described in Section 12.1 and then proceed as follows:

1. **Capture the Newly Created Certificate:** Type 13 and press **[Enter]** (View CSR). The SRM will prompt you to configure your communications (Telnet) program to receive the certificate. Set up your communications program to receive a binary file, and then press **[Enter]** to capture the file and save it. This is the Code Signing Request that you will send to the outside security service (e.g., VeriSign, Thawte, etc.) in order to have them sign and activate the certificate.
2. **Obtain the Signed Certificate:** Send the captured certificate to the outside security service. Refer to the security service's web page for further instructions.

3. **Upload the Signed Certificate to the SRM:** After the "signed" certificate is returned from the security service, return to the Web Access menu.
 - a) Access the SRM command mode via the Text Interface using an account that permits Administrator level commands as described previously, then type **/N** and press **[Enter]** to display the Network Parameters menu, and then type **23** and press **[Enter]** to display the Web Access menu.
 - b) From the Web Access menu, type **14** and press **[Enter]** (Import CRT) to begin the upload process. At the CRT Server Key submenu, type **1** and press **[Enter]** to choose "Upload Server Key."
 - c) Use your communications program to send the binary format Signed Certificate to the SRM unit. When the upload is complete, press **[Escape]** to exit from the CRT Server Key submenu.
 - d) After you exit from the CRT Server Key submenu, press **[Escape]** several times until you have exited from the Network Parameters menu and the "Saving Configuration" message is displayed.
4. After the configuration has been saved, test the signed certificate by accessing the SRM via the Web Browser Interface, using an HTTPS connection. For example, if the common name has been defined as "service.wti.com", then you would enter "**https://service.wti.com**" in your web browser's address field. If the Signed Certificate has been properly created and uploaded, the warning message should no longer be displayed.

12.3. Downloading the Server Private Key

When configuring the SRM's SSL encryption feature (or setting up other security/authentication features), it is recommended to download and save the Server Private Key. To download the Server Private Key, access the Text interface via Telnet or SSH, using a password that permits access to Administrator level commands and then proceed as follows:

1. Type **/N** and press **[Enter]** to display the Network Parameters menu.
2. At the Network Parameters menu, type **23** and press **[Enter]** to display the Web Access menu (Figure 12.1.)
 - a) To download the Server Private Key from the SRM unit, make certain that SSL parameters have been defined as described in Section 12.1, then type **15** and press **[Enter]** and store the resulting key on your hard drive.
 - b) To upload a previously saved Server Private Key to the SRM unit, make certain that SSL parameters have been defined as described in Section 12.1, then type **16** and press **[Enter]** and follow the instructions in the resulting submenu.

12.4. TLS Mode

The TLS Mode parameter in the Web Access menu (Text Interface Only) allows the TLS Mode to be set to either TLSv1 or TLSv1.1. Although TLSv1.1 provides better security, the default settings of most browsers do not support TLSv1.1. The default setting for this parameter is TLSv1.

13. Saving and Restoring Configuration Parameters

Once the SRM is properly configured, parameters can be downloaded and saved. Later, if the configuration is accidentally altered, the saved parameters can be uploaded to automatically reconfigure the unit without the need to manually assign each parameter.

Saved parameters can also be uploaded to other identical SRM units, allowing rapid set-up when several identical units will be configured with the same parameters.

The "Save Parameters" procedure can be performed from any terminal emulation program (e.g. HyperTerminal™, TeraTerm®, etc.), that allows downloading.

Note: *Configuration parameters can be downloaded and saved via either the Web Browser Interface or Text Interface. Saved configuration parameters can only be uploaded to the SRM unit via the Text Interface.*

13.1. Sending Parameters to a File

13.1.1. Downloading & Saving Parameters via Text Interface

1. Access the Text Interface command mode using an account that permits Administrator level commands.
2. When the command prompt appears, type `/U` and press **[Enter]**. The SRM will prompt you to configure your terminal emulation program to receive an ASCII download.
 - a) Set your terminal emulation program to receive an ASCII file, and then specify a name for a file that will receive the saved parameters (e.g., TSM.PAR).
 - b) Disable the Line Wrap function for your terminal emulation program. This will prevent command lines from being broken in two during transmission.
3. When the terminal emulation program is ready to receive the file, return to the SRM's Save Parameter File menu, and press **[Enter]** to proceed. SRM parameters will be saved on your hard drive in the file specified in Step 2 above.
4. The SRM will send a series of command lines which specify currently selected parameters. When the download is complete, press **[Enter]** to return to the command prompt.

13.1.2. Downloading & Saving Parameters via Web Browser Interface

The Web Browser Interface also includes a download function that can be used to save SRM parameters to an XML format file on your PC or laptop. To save parameters via the Web Browser Interface, proceed as follows:

Notes:

- *Although SRM parameters can be saved to a file via either the Text Interface or Web Browser Interface, saved parameters can only be restored via the Text Interface. The Restore Parameters function is not available via the Web Browser Interface.*
 - *This procedure may differ slightly, depending on the operating system and browser used. In some cases, your system may perform a security scan before proceeding with the download.*
1. Access the Web Browser Interface command mode using an account that permits Administrator level commands.
 2. When the Web Browser Interface appears, click on the "Download Unit Configuration" button on the left hand side of the screen.
 3. After a brief pause, your browser may display a prompt asking if you want to open or save the downloaded file. At this point, you can either select the "Save" option to save the parameters file to the download folder on your PC, or select "Save As" to pick a different location and/or filename for the saved parameters file.

13.2. Restoring Downloaded Parameters

This section describes the procedure for using your terminal emulation program to send saved parameters to the SRM.

Note: *The Restore Parameters feature is only available via the Text Interface.*

1. Start your terminal emulation program and access the SRM's Text Interface command mode using an account that permits Administrator level commands.
2. Configure your terminal emulation program to upload an ASCII file.
3. Upload the ASCII text file with the saved SRM parameters. If necessary, key in the file name and directory path.
4. Your terminal emulation program will send the ASCII text file to the SRM. When the terminal program is finished with the upload, make certain to terminate the Upload mode.

Note: *If the SRM detects an error in the file, it will respond with the "Invalid Parameter" message. If an error message is received, carefully check the contents of the parameters file, correct the problem, and then repeat the Upload procedure.*

5. If the parameter upload is successful, the SRM will send a confirmation message, and then return to the command prompt. Type **/s** and press **[Enter]**, the Status Screen will be displayed. Check the Status Screen to make certain the unit has been configured with the saved parameters.

13.3. Restoring Recently Saved Parameters

If you make a mistake while configuring the SRM unit, and wish to return to the previously saved parameters, the Text Interface's "Reboot System" command (/I) offers the option to reinitialize the SRM using previously backed up parameters. This allows you to reset the unit to previously saved parameters, even after you have changed parameters and saved them.

Notes:

- *The SRM will automatically backup saved parameters once a day, shortly after Midnight. This configuration backup file will contain only the most recently saved SRM parameters, and will be overwritten by the next night's daily backup.*
- *When the /I command is invoked, a submenu will be displayed which offers several Reboot options. Option 4 is used to restore the configuration backup file. The date shown next to option 4 indicates the date that you last changed and saved unit parameters.*
- *If the daily automatic configuration backup has been triggered since the configuration error was made, and the previously saved configuration has been overwritten by newer, incorrect parameters, then this function will not be able to restore the previously saved (correct) parameters.*

To restore the previously saved configuration, proceed as follows:

1. Access command mode via the Text Interface, using a username/password that permits access to Administrator level commands (see Section 5.1.1.)
2. At the RSM command prompt, type /I and press **[Enter]**. The SRM will display a submenu that offers several different reboot options.
3. At the submenu, select Item 4 (Reboot & Restore Last Known Working Configuration,) type 4, and then press **[Enter]**.
4. The SRM will reboot and previously saved parameters will be restored.

14. Upgrading SRM Firmware

When new, improved versions of the SRM firmware become available, either the Firmware Upgrade Utility (recommended) or the "Upgrade Firmware" function (Text Interface only) can be used to update the unit. The following Section describes the procedure for updating the SRM unit using the Firmware Upgrade Utility or the Upgrade Firmware function.

14.1. WMU Enterprise Management Software (Recommended)

The preferred method for updating SRM units is via the WMU Enterprise Management Software that is included with the unit. The WMU software allows you to manage firmware updates for multiple WTI units from a single interface. For a description of the process for managing firmware updates via the WMU, please refer to the WMU user's guide, which can be downloaded from the WTI User's Guide Archive at:

<http://www.wti.com/t-product-manuals.aspx>

Note that in order to use the WMU software, the firmware version for the SRM must be at least v6.23 or higher. When upgrading older SRM units that feature pre v6.23 firmware, it is recommended to use the WTI Firmware Upgrade Utility. A zip file that contains the installation files and other documentation for the WTI Firmware Upgrade Utility can be downloaded from WTI's FTP server, located at:

ftp://wtift.wti.com/pub/TechSupport/Firmware/Upgrade_Utility/

Please refer to the documentation included in the zip file for further instructions.

14.2. The Upgrade Firmware Function (Alternate Method)

The Upgrade Firmware function provides an alternative method for updating the SRM firmware. Updates can be uploaded via FTP or SFTP protocols.

Notes:

- *The FTP/SFTP servers can only be started via the Text Interface.*
 - *All other ports will remain active during the firmware upgrade procedure.*
 - *If the upgrade includes new parameters or features not included in the previous firmware version, these new parameters will be set to their default values.*
 - *The upgrade procedure will require approximately 15 minutes.*
1. Obtain the update file. Firmware modifications can either be mailed to the customer, or downloaded from WTI. Place the upgrade CDR in your disk drive or copy the file to your hard drive.
 2. Access Text Interface command mode via Serial Port, Telnet or SSH client session, using a username/password and port that permit Administrator level commands.

3. When the command prompt appears, type `/UF` and then press **[Enter]**. The SRM will display a screen which offers the following options:
 - a) **Start FTP/SFTP Servers Only (Do NOT default parameters):** To proceed with the upgrade, while retaining user-defined parameters, type 1 and press **[Enter]**. All existing parameter settings will be restored when the upgrade is complete.
 - b) **Start FTP/SFTP Servers & Default (Keep IP parameters & SSH Keys):** To proceed with the upgrade and default all user-defined parameters except for the IP Parameters and SSH Keys, type 2 and press **[Enter]**. When the upgrade is complete, all parameter settings except the IP Parameters and SSH Keys, will be reset to factory default values.
 - c) **Start FTP/SFTP Servers & Default (Default ALL parameters):** To proceed with the upgrade, and reset parameters to default settings, type 3 and press **[Enter]**. When the upgrade is complete, all parameters will be set to default values.
 - d) **Start FTP/SFTP Servers for Slip Stream Upgrade:** This option will upgrade only the WTI Management Utility, without updating the SRM's operating firmware. To update the WTI Management Utility only, type 4 and press **[Enter]**.

Note that after any of the above options is selected, the SRM will start the receiving servers and wait for an FTP/SFTP client to make a connection and upload a valid firmware binary image.

4. To proceed with the upgrade, select either option 1 or option 2. The SRM will display a message that indicates that the unit is waiting for data. Leave the current Telnet/SSH client session connected at this time.
5. Open your FTP/SFTP application and (if you have not already done so,) login to the SRM unit, using a username and password that permit access to Administrator Level commands.
6. Transfer the md5 format upgrade file to the SRM.
7. After the file transfer is complete, the SRM will install the upgrade file and then reboot itself and break all port connections. Note that it will take approximately 10 minutes to complete the installation process. The unit will remain accessible until it reboots.
 - a) Some FTP/SFTP applications may not automatically close when the file transfer is complete. If this is the case, you may close your FTP/SFTP client manually after it indicates that the file has been successfully transferred.
 - b) When the upgrade process is complete, the SRM will send a message to all currently connected network sessions, indicating that the SRM is going down for a reboot.

Note: Do not power down the SRM unit while it is in the process of installing the upgrade file. This can damage the unit's operating system.

8. If you have accessed the SRM via the Network Port, in order to start the FTP/SFTP servers, the SRM will break the network connection when the system is reinitialized.
 - If you initially selected "Start FTP/SFTP Servers and Save Parameters", you may then reestablish a connection with the SRM using your former IP address.
 - If you initially selected "Start FTP/SFTP Servers and Default Parameters", you must then login using the SRM's default IP address (Default = 192.168.168.168) or access command mode via Serial Port 1 or via Modem.

When firmware upgrades are available, WTI will provide the necessary files. At that time, an updated Users Guide or addendum will also be available.

15. Command Reference Guide

15.1. Command Conventions

Most commands described in this section conform to the following conventions:

- **Apply Command to All Ports:** When an asterisk is entered as the argument of the /D (Disconnect) command, the command will be applied to all ports. For example, to erase all port buffers, type /D * [Enter].
- **Suppress Command Confirmation Prompt:** When any command that normally requires confirmation is invoked, the ",Y" option can be included to override the Command Confirmation ("Sure?") prompt. For example, to reboot Plug 4 without displaying the Sure prompt, type /D 1 3,Y [Enter].
- **Connected Ports:** When two ports are connected, most SRM commands will not be recognized by either of the connected ports. The only exception is the Resident Disconnect Sequence (Default = ^x ([Ctrl] plus [X]).)

15.2. Command Summary

Function	Command Syntax	Command Access Level			
		Admin.	SuperUser	User	ViewOnly
Display					
Port Status	/S [Enter]	X❶	X❶	X❶	X❶
Port Diagnostics	/SD [Enter]	X❶	X❶	X❶	X❶
Port Parameters (Who)	/W [n] [Enter]	X❶	X❶	X❷	X❷
Network Status	/SN [Enter]	X	X	X	X
Network Configuration Summary	/RN [Enter]	X	X	X	X
Alarm Status	/AS [alarm] [Enter]	X			
Help Menu	/H [Enter]	X	X	X	X
Log Functions	/L [Enter]	X	X		
Site ID / Unit Information	/J [*] [Enter]	X	X	X	X
Control					
Exit Command Mode	/X [Enter]	X	X	X	X
Connect - Local <Remote>	/C <n> [n] [Enter]	X	X	X❸	
Disconnect Ports	/D <n Nn *> [Enter]	X	X		
Send Parameter File	/U [Enter]	X			
Send SSH Keys	/K <n> [Enter]	X			
Unlock Invalid Access	/UL [Enter]	X			
Outbound Telnet	/TELNET <ip> [port] [Enter]	X❹	X❹	X❹	
Outbound SSH	/SSH <ip> -l <username> [Enter]	X❹	X❹	X❹	
Configuration					
System Parameters	/F [Enter]	X	❸		
Serial Port Parameters	/P [Enter]	X	❸		
Network Configuration - IPv4	/N [Enter]	X	❸		
Network Configuration - IPv6	/N6 [Enter]	X	❸		
Ping No Answer Configuration	/PNA [Enter]	X	❸		
Alarm Configuration	/AC [Enter]	X	❸		
Reboot System	/I [Enter]	X	X		
Upgrade Firmware	/UF [Enter]	X			
Test Network Configuration	/TEST [Enter]	X			

- ❶ In Administrator and SuperUser mode, all ports are displayed. In User and ViewOnly mode, the screen will only display ports allowed by the account.
- ❷ User and ViewOnly level accounts are only allowed to view parameters for the port that was used to access command mode.
- ❸ User level accounts are only allowed to create a connection to Serial Ports permitted by the account. User level accounts are not allowed to create Third Party (remote) port connections.
- ❹ In order to invoke this command, Outbound Telnet/SSH and Outbound Service Access must be enabled for your account.
- ❺ In SuperUser mode, configuration menus can be displayed, but parameters cannot be changed.

15.3. Command Set

This Section provides information on all Text Interface commands, sorted by functionality

15.3.1. Display Commands

/S Display Port Status Screen

Displays the Port Status Screen, which lists the current status of the SRM's serial ports. For more information, please refer to Section 8.3.

Note: *In Administrator Mode and SuperUser Mode, all SRM ports are displayed. In User Mode and ViewOnly Mode, the Plug Status Screen will only include the ports allowed by your account.*

Availability: Administrator, SuperUser, User, ViewOnly

Format: /s [Enter]

/SD Display Port Diagnostics

Provides detailed information regarding the status of each port. When this command is issued by a User level or View Only level account, the resulting screen will only display parameters for the ports allowed by the account. For more information, please refer to Section 8.4.

Availability: Administrator, SuperUser, User, ViewOnly

Format: /SD [Enter]

Response: Displays Port Diagnostics Screen.

/W Display Port Parameters (Who)

Displays configuration information for an individual port, but does not allow parameters to be changed. User and ViewOnly accounts can only display parameters for their resident port. For more information, please refer to Section 8.6.

Availability: Administrator, SuperUser, User, ViewOnly

Format: /w [x] [Enter]

Where **x** is the port number or name. To display parameters for the Network Port, enter an "N". If the "x" argument is omitted, parameters for your resident port will be displayed.

Example: To display parameters for a port named "MODEM", access the Command Mode from a port and account that permits Administrator level commands, and type /w MODEM [Enter].

/SN Display Network Status

Displays the Network Status Screen, which lists current network connections to the SRM's Network Port. For more information, please refer to Section 8.2.

Availability: Administrator, SuperUser, User, ViewOnly

Format: /SN [Enter]

/RN Network Configuration Summary

Displays a screen that lists currently selected communication settings, LDAP status, RADIUS status, Email Messaging status, NTP status and PPP status.

Availability: Administrator, SuperUser, User ViewOnly

Format: /RN [Enter]

/V View Connection (with Echo)

When two SRM ports have been connected, the /V command can be used to display data that is sent between the two connected serial ports, including data that has been echoed.

Note: To display data sent between two connected serial ports without including echoed data, please refer to the /VE command.

Availability: Administrator, SuperUser

Format: /v <n> [Enter]

Where **n** is the number of one of the two connected serial ports.

/VE View Connection (without Echo)

When two SRM ports have been connected, the /VE command can be used to display data that is sent between the two connected serial ports, but will not include data that has been echoed.

Note: To display data sent between two connected serial ports, including echoed data, please refer to the /V command.

Availability: Administrator, SuperUser

Format: /vE <n> [Enter]

Where **n** is the number of one of the two connected serial ports.

/H Help

Displays a Help Screen, which lists all available Text Interface commands along with a brief description of each command.

Note: In the Administrator Mode, the Help Screen will list the entire SRM command set. In SuperUser Mode, User Mode and ViewOnly Mode, the Help Screen will only list the commands that are allowed for that Access Level.

Availability: Administrator, SuperUser, User, ViewOnly

Format: /H [Enter]

/L Log Functions

Provides access to a menu which allows you to display the Audit Log, Alarm Log and Temperature Log. For more information on Log Functions, please refer to Section 6.2.3.

Availability: Administrator, SuperUser

Format: /L [Enter]

/AS Alarm Status Screen

Lists all available user-defined alarms and indicates whether or not each alarm has been triggered as described in Section 7. The resulting screen will display "Yes" (or 1) for alarms that have been triggered or "No" (or 0) for alarms that have not been triggered. If desired, the /AS command line can also include an optional alarm argument that will cause the unit to display the status of one individual alarm as shown in the table below:

Alarm Name	Alarm Argument
Over Temperature (Initial)	OTI
Over Temperature (Critical)	OTC
Ping No Answer	PNA
Serial Port Invalid Access Lockout	LO
Power Cycle (Cold Boot)	CB
No Dialtone	ND

Availability: Administrator

Format: /AS [**alarm**] [Enter]

Where **alarm** is an optional argument, which can be used to display the status of an individual alarm as shown in the table above.

/J Display Site ID / Unit Information

Displays the user-defined Site I.D. message. If the optional asterisk (*) argument is included in the command line, the command can also display the model number, serial number, software version and other information for the SRM unit.

Availability: Administrator, SuperUser, User, ViewOnly

Format: /J [*] [Enter]

Where * is an optional argument, which can be included in the command line to display the exact model number and software version of the SRM unit.

15.3.2. Control Commands

/X Exit Command Mode

Exits command mode. When issued at the Network Port, also ends the Telnet session.

Note: *If the /X command is invoked from within a configuration menu, recently defined parameters may not be saved. In order to make certain that parameters are saved, always press the [Esc] key to exit from all configuration menus and then wait until "Saving Configuration" message has been displayed and the cursor has returned to the command prompt before issuing the /X command.*

Availability: Administrator, SuperUser, User, ViewOnly

Format: /x [Enter]

/C Connect

Establishes a bidirectional connection between two ports. There are two types of connections:

- **Resident Connect:** If the /C command specifies only one port, your resident port will be connected to the specified port.
- **Third Party Connect:** If the /C command specifies two ports, the unit will connect the two ports indicated. Third Party Connections can only be initiated by ports and accounts that permit Administrator level commands.

Notes:

- *User level accounts can only connect to the ports that are specifically permitted by the account.*
- *User level accounts are not allowed to create "Third Party" connections. For example, a User level account, that is logged in via the Network Port cannot connect Serial Port 2 to Port 3.*
- *Administrator and SuperUser level accounts are allowed to connect to any SRM Serial Port.*
- *The Serial Ports are not allowed to create a Third Party connection to the Network Port. For example, Serial SetUp Port (port 1) cannot connect Serial Port 2 to the Network Port.*

Availability: Administrator, SuperUser, User

Format: /C <x> [x] [Enter]

Where x is the number or name of the port(s) to be connected.

/D Third Party Disconnect

Invoke the /D command at your resident port to disconnect two other ports.

Notes:

- The /D command cannot disconnect your resident port
- SuperUsers and Users are limited to the ports that are specifically allowed by their accounts.

Availability: Administrator, SuperUser

Format: /D [/Y] <x> [x] [Enter]

Where:

- /Y (Optional) suppresses the "Sure?" prompt.
- x Is the number or name of the port(s) to be disconnected. To disconnect all allowed ports, enter an asterisk. To disconnect a Telnet session, enter the "nn" format Network Port Number.

Example: To disconnect Port 2 from Port 3 without the "Sure?" prompt, access the Command Mode from a third port with Administrator level command capability and type:

/D/Y 2 [Enter] or /D/Y 3 [Enter]

/U Send Parameters to File

Sends all SRM configuration parameters to an ASCII text file as described in Section 13. This allows you to back up the configuration of your SRM unit.

Availability: Administrator

Format: /U [Enter]

/K Send SSH Key

Instructs the SRM to provide you with a public SSH key for validation purposes. This public key can then be provided to your SSH client, in order to prevent the SSH client from warning you that the user is not recognized when you attempt to create an SSH connection. For more information, please refer to Section 9.2.

Availability: Administrator

Format: /K k [Enter]

Where k is a required argument, which indicates the key type. The k argument provides the following options: 1 (SSH1), 2 (SSH2 RSA), 3 (SSH2 DSA.)

/UL Unlock Port (Invalid Access Lockout)

Manually cancels the SRM's Invalid Access Lockout feature. Normally, when a series of failed login attempts are detected, the Invalid Access Lockout feature can shut down the effected port or protocol for a user specified time period in order to prevent further access attempts. When the /UL command is invoked, the SRM will immediately unlock all ports and protocols that are currently in the locked state.

Availability: Administrator

Format: /UL [Enter]

/TELNET Outbound Telnet

Creates an outbound Telnet connection.

Notes:

- *In order for the /TELNET command to function, Telnet/SSH and Outbound Service Access must be enabled for your user account as described in Section 6.4. In addition, Telnet Access and Outbound Access must also be enabled via the Network Parameters menu, as described in Section 6.6.2.*
- *If you have logged in via the Network Port, the /TELNET command will not function.*

Availability: Administrator, SuperUser, User

Format: /TELNET <ip> [port] [Enter]

Where:

- | | |
|-------------|--|
| ip | Is the target IP address. The IP Address can be entered in either IPv4 or IPv6 format. |
| port | Is an optional argument which can be included to indicate the target port at the IP address. |

/SSH Outbound SSH

Creates an outbound SSH connection.

Notes:

- *In order for the /SSH command to function, Telnet/SSH and Outbound Service Access must be enabled for your user account as described in Section 6.4. In addition, SSH Access and Outbound Access must also be enabled via the Network Parameters menu, as described in Section 6.6.2.*
- *If you have logged in via the Network Port, the /SSH command will not function.*

Availability: Administrator, SuperUser, User

Format: /SSH <ip> -l <username> [Enter]

Where:

- | | |
|-----------------|--|
| ip | Is the target IP address. The IP Address can be entered in either IPv4 or IPv6 format. |
| -l | (Lowercase letter "L") Indicates that the next argument will be the log on name. |
| username | Is the username that you wish to use to log in to the target device. |

15.3.3. Configuration Commands

/F Set System Parameters

Displays a menu used to define general system parameters for the SRM unit. All functions provided by the /F command are also available via the Web Browser Interface. For more information, please refer to Section 6.2.

Availability: Administrator

Format: /F [Enter]

/P Set Serial Port Parameters

Displays a menu used to select parameters for the Serial SetUp Ports, Serial Modem Port and internal Modem. All functions provided by the /P command are also available via the Web Browser Interface. Section 6.5 describes the procedure for defining serial port parameters.

Availability: Administrator

Format: /P <n> [Enter]

Where <n> is the number or name of the desired serial port. The SetUp Port is Port 1, The Modem Port is Port 2 and the Modem is Port 3.

/N Network Port Parameters - IPv4

Displays a menu used to select IPv4 protocol parameters for the Network Port. All functions provided by the /N command are also available via the Web Browser Interface. For more information, please refer to Section 6.6.

Availability: Administrator

Format: /N [Enter]

/N6 Network Port Parameters - IPv6

Displays a menu used to select IPv6 protocol parameters for the Network Port. All functions provided by the /N6 command are also available via the Web Browser Interface. For more information, please refer to Section 6.6.

Availability: Administrator

Format: /N6 [Enter]

/PNA Ping No Answer Configuration Parameters

Displays a menu that is used to define IP addresses and other associated parameters that will be used by the Ping No Answer Alarm. When Ping No Answer IP addresses have been defined and the Ping No Answer Alarm has been enabled, the SRM can ping user-defined IP addresses, and notify you when devices at those IP addresses are not responding to the ping command. For more information, please refer to Section 7.2.1.1.

Availability: Administrator

Format: /PNA [Enter]

/AC Alarm Configuration Parameters

Displays a menu that is used to configure and enable the SRM's monitoring and alarm functions. For more information on Alarm Configuration, please refer to Section 7.

Availability: Administrator

Format: /AC [Enter]

/I Reboot System (Default)

Reinitializes the SRM unit and offers the option to keep user-defined parameters or reset to default parameters. As described in Sections 6.7.1 and 13.3, the /I command can also be used to restore the unit to previously saved parameters. When the /I command is invoked, the unit will offer four reboot options:

- Reboot Only (Do NOT default parameters)
- Reboot & Default (Keep IP Parameters & SSH Keys; Default all other parameters)
- Reboot & Default (Default ALL parameters)
- Reboot & Restore Last Known Working Configuration

Availability: Administrator

Format: /I [Enter]

/UF Upgrade Firmware

When new versions of the SRM firmware become available, this command is used to update existing firmware as described in Section 14.

Notes:

- *The WMU Enterprise Management Software is the preferred method for managing SRM firmware upgrades. The /UF command is intended to provide an alternative to the WMU Enterprise Management Software. For more information, please refer to Section 14.1*
- *When a firmware upgrade is performed, the SRM will require 15 minutes for the upgrade procedure.*

Availability: Administrator

Format: /UF [Enter]

/TEST Test Network Parameters

Displays a menu which is used to test configuration of the Syslog and SNMP Trap functions and can also be used to ping a user-selected IP address.

Notes:

- *In order for a ping test to function properly, your network and/or firewall and the target device must be configured to allow ping commands.*
- *In order for the ping command to function with domain names, Domain Name Server parameters must be defined as described in Section 6.6.5.*
- *The Test Menu's Ping command is not effected by the status of the Network Parameters Menu's Ping Access function.*

Availability: Administrator

Format: /TEST [Enter]

Appendix A. Specifications

Network Interface: 10/100/1000Base-T Ethernet, RJ45, multi-session Telnet.

RS232 Port Interface:

SetUp Port:

- One (1) RJ45 connector (DTE pinout)
- One (1) USB Mini connector

Modem Port:

- One (1) RJ45 connector (DCE pinout)
- One (1) DB25 connector (DCE pinout)

Coding: 7/8 bits, Even, Odd, No Parity, 1, 2 Stop Bits.

Flow Control: XON/XOFF, RTS/CTS, Both, or None.

Data Rate: 300 to 115.2K bps (all standard rates).

Inactivity Timeout: No activity timeout disconnects port/modem sessions.
Off, 5, 15, 30, 90 minutes.

Internal Modem: Internal 56K v.92 Modem (Optional)

Internal Modem Port (Phone Line): RJ11 connector for connection to your Telco line

Break: Send Break or Inhibit Break

Site ID: 32 Characters.

Usernames & Passwords: 16 characters each (case sensitive.) Up to 128 pairs.

LEDs: On, Ready, DCD, RXD, DTR, TXD, Setup Port Activity, Modem Port Activity, Dialtone.

Physical / Environmental:

Size:

Width: 19" (48.3 cm)

Height: 1.75" (4.4 cm)

Depth: 4.60" (11.7 cm)

Power:

SRM-100 Series: IEC-320-C14 Inlet, 100 to 240 VAC, 50/60 Hz, 0.2 Amp Max.

SRM-100DC Series: Terminal Strip (#6-32), -48 VDC, 0.3 Amp Max.

Operating Temperature: 32°F to 140°F (0°C to 60°C)

Storage Temperature: -4°F to 128°F (-20°C to 70°C)

Humidity: 10 to 90% RH, Non-Condensing

Venting: Side vents are used to dissipate heat generated within the unit. When mounting the unit in an equipment rack, make certain to allow adequate clearance for venting.

Appendix B. Interface Descriptions




Figure B.1: RJ45 SetUp Port (DTE)




Figure B.2: DB25 Modem Port (DCE)





Figure B.3: RJ45 Modem Port (DCE)



- 1 Not Used**
- 2 Not Used**
- 3 RING**
- 4 TIP**
- 5 Not Used**
- 6 Not Used**

Figure B.4: RJ11 Phone Line Port

Appendix C. Customer Service

Customer Service hours are from 8:00 AM to 5:00 PM, PST, Monday through Friday. When calling, please be prepared to give the name and make of the unit, its serial number and a description of its symptoms. If the unit should need to be returned for factory repair it must be accompanied by a Return Authorization number from Customer Service.

WTI Customer Service
5 Sterling
Irvine, California 92618

Local Phone: (949) 586-9950
Toll Free Service Line: 1-888-280-7227
Service Fax: (949) 583-9514

Email: service@wti.com

Trademark and Copyright Information

WTI and Western Telematic are trademarks of Western Telematic Inc.. All other product names mentioned in this publication are trademarks or registered trademarks of their respective companies.

Information and descriptions contained herein are the property of Western Telematic Inc.. Such information and descriptions may not be copied, disseminated, or distributed without the express written consent of Western Telematic Inc..

© Copyright Western Telematic Inc., 2015.

November, 2015

Part Number: 14439, Revision: A

Trademarks and Copyrights Used in this Manual

Hyperterminal is a registered trademark of the Microsoft Corporation. Portions copyright Hilgraeve, Inc.

Teraterm is a copyright of Ayera Technologies, Inc.

BlackBerry is a registered trademark of Research In Motion Limited.

JavaScript is a trademark of Sun Microsystems, Inc.

Telnet is a trademark of Telnet Communications, Inc.

Thawte is a trademark of Thawte, Inc.

VeriSign is a registered trademark of VeriSign, Incorporated

All other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.